


# **WORKSHOP MANUAL SUPPLEMENT**



*Published by*  
**Austin Morris Group**  
**Service and KD Division**  
**Cowley, Oxford, England**

© BRITISH LEYLAND MOTOR CORPORATION LIMITED, 1973

## FOREWORD

This supplement provides service operatives with the information necessary to carry out the maintenance, servicing, and testing of engine emission and fuel evaporative loss control systems fitted to vehicles manufactured by BRITISH LEYLAND (AUSTIN-MORRIS) LTD. for which a certificate has been issued in accordance with the UNITED STATES CLEAN AIR ACTS and any applicable State Legislation.

Distributors and Dealers are advised to familiarize themselves with the legal requirements, in particular those concerning minimum standards of facilities, personnel, and servicing equipment.

Service operations in Workshop Manuals, where applicable, which may affect the efficiency of the emission or evaporative loss control equipment carry the following symbol, denoting that the control system must be checked on completion of the operation



## INDEX

	<i>Section</i>
Carburettors .. .. .	4
Crankcase emission control .. .	2
Equipment .. .. .	1
Exhaust emission control .. .	3
Fuel evaporative loss control system .. .	5
Tuning data .. .. .	6
Tune-up chart .. .. .	End of Supplement
Exhaust emission control—engine modification system.. .	3A





# SECTION 1

## EQUIPMENT AND SERVICING

	<i>Section</i>
Equipment .. .. .	1-A
Servicing .. .. .	1-B
Fault diagnosis	
General servicing	

## EQUIPMENT AND SERVICING

### Section 1-A

#### EQUIPMENT

The recommended equipment for servicing should include at least the following:

Ignition Analyser Oscilloscope	Cam Angle Dwell Meter
Ohmmeter	Ignition Timing Light
Voltmeter	Engine Exhaust Combustion Analyser
Tachometer	Cylinder Leak Tester
Vacuum Gauge	Distributor Advance Tester
Pressure Gauge (0–10 lb./sq. in.)	Carburetter Piston Loading Tool
Carburetter Balance Meter	

The following equipment covers most of the requirements for engine testing and tuning vehicles fitted with exhaust emission control devices.

<i>Equipment</i>	<i>Type/Model</i>	<i>Manufacturer</i>
Oscilloscope Engine		
Tuning Set and Exhaust		
Gas Analyser .. .. .	1020 or 720 .. .. .	Sun Electric Corp.
Engine Analyser .. .. .	40–162 .. .. .	Marquette
Exhaust Gas Analyser .. .. .	42–141 .. .. .	Marquette

Equipment made by other suppliers may also be adequate.

It is important that your test equipment has regular maintenance and calibration.

### Section 1-B

#### SERVICING

##### General

The efficient operation of the exhaust emission control system is dependent on the engine being in good mechanical condition and correctly tuned to the settings given in 'TUNING DATA'.

Tuning and test procedure for the carburetters, ignition system, and engine are given at the end of the manual. These procedures are the quickest and surest way of locating engine faults or maladjustments and are the only methods that should be used for engine tuning.

##### Fault diagnosis

After tuning the engine to the correct settings, check for indications of the following symptoms:

<b>Symptoms</b>	<b>Causes</b>	<b>Cure</b>
Backfire in exhaust system	1. Leak in exhaust system	Locate and rectify leak
	2. Leaks in hoses or connections to gulp valve, vacuum sensing pipe or other inlet manifold joint	Locate and rectify leak
	3. Faulty gulp valve	Test gulp valve, and renew if faulty
	4. Leak in intake system	Locate and rectify leak
	5. High inlet manifold depression on over-run—faulty carburetter limit valve	Fit new throttle disc and limit valve assembly

## EQUIPMENT AND SERVICING

Symptoms	Causes	Cure
Hesitation to accelerate after sudden throttle closure	1. Low carburettor damper oil	Top up to correct level
	2. Leaks in hoses or connections to gulp valve, vacuum sensing pipe or other inlet manifold joint	Locate and rectify leak
	3. Faulty gulp valve	Test gulp valve, and renew if faulty
	4. Leak in intake system	Locate and rectify leak
Engine surges (erratic operation at varying throttle openings)	1. Leaks in hoses or connections to gulp valve, vacuum sensing pipe or other inlet manifold joint	Locate and rectify leak
	2. Faulty gulp valve	Test gulp valve, and renew if faulty
	3. Air supply to adsorption canister restricted	Check air filter pad, vent pipe, and canister for obstruction
Erratic idling or stalling	1. Carburettor damper oil low	Top up to correct level.
	2. Leaks in hoses or connections to gulp valve or vacuum sensing pipe or other inlet manifold joint	Locate and rectify leak
	3. Faulty gulp valve	Test gulp valve, and renew if faulty
	4. Incorrect carburettor settings	Reset to <b>TUNING DATA</b>
	5. Carburettor limit valve not seating	Fit new throttle disc and limit valve assembly
	6. Carburettor suction chamber damaged	Replace carburettor or components
Burned or baked hose between air pump and check valve	1. Faulty check valve	Test check valve, and renew if faulty
	2. Air pump not pumping	Test air pump; service or renew if faulty
Noisy air pump	1. Incorrect belt tension	Adjust belt tension
	2. Pulleys damaged, loose or mis-aligned	Tighten loose pulleys, renew damaged pulleys
	3. Air pump failing or seizing	Test air pump; service or renew if faulty
Excessive exhaust system temperature	1. Incorrect ignition timing	Recheck timing against ' <b>TUNING DATA</b> '
	2. Choke control system not fully returned	Check choke mechanism for correct operation; instruct driver on correct usage
	3. Fast idle speed too high	Reset fast idle speed—see ' <b>TUNING DATA</b> '
	4. Air injector missing	Remove air manifold and check injectors
	5. Air pump relief valve inoperative	Test relief valve, and renew if faulty

## EQUIPMENT AND SERVICING

Symptoms	Causes	Cure
Mixture requires excessive enriching to obtain correct exhaust emission readings	<ol style="list-style-type: none"> <li>1. Air leak into crankcase</li> <li>2. Early cars—Diaphragm of crankcase control valve perforated or not correctly seated</li> <li>Later cars—Crankcase breather hose or connections to carburetter leaking</li> </ol>	<p>Locate and rectify leak</p> <p>Locate and rectify leak or control valve</p> <p>Locate and rectify leak</p>
Fuel leakage	<ol style="list-style-type: none"> <li>1. Fracture in fuel pipe or fuel vapour ventilation system</li> <li>2. Fuel filler cap not sealing</li> <li>3. Leak on fuel filler tube or tank unit</li> </ol>	<p>Locate and rectify leak</p> <p>Check condition of cap and filler seal</p> <p>Locate and rectify leak</p>
Engine stops after short running periods (i.e. fuel starvation)	<ol style="list-style-type: none"> <li>1. Obstructed vapour line between fuel tank and absorption canister</li> <li>2. Air supply to absorption canister restricted</li> <li>3. Faulty fuel pump</li> </ol>	<p>Locate and clear obstruction</p> <p>Check air filter pad, vent pipe and canister for obstruction</p> <p>Check operation and rectify fault</p>
Engine runs after ignition is switched off	<ol style="list-style-type: none"> <li>1. Fuel grade too low</li> <li>2. Ignition retarded</li> <li>3. Idle speed too high</li> <li>4. Fuel mixture too weak</li> </ol>	<p>Refill with correct grade fuel</p> <p>Reset timing to 'TUNING DATA'</p> <p>Reset to 'TUNING DATA'</p> <p>Tune carburetter(s)</p>



## SECTION 2

### CRANKCASE EMISSION CONTROL

	<i>Section</i>
Carburettor control system .. .. .	2-D
Carburettor control system—with evaporative loss control .. .. .	2-E
Valve control system—general description .. .. .	2-A
Valve control system—servicing .. .. .	2-C
Valve control system—testing .. .. .	2-B






Fig. 1

D O 4 6 9

*A typical crankcase emission valve control system*

- |                            |                         |                          |
|----------------------------|-------------------------|--------------------------|
| 1. Emission control valve. | 5. Cover plate.         | 8. Breather hose.        |
| 2. Valve spring.           | 6. Spring clip.         | 9. Oil separator.        |
| 3. Metering valve.         | 7. Manifold connection. | 10. Filtered filler cap. |
| 4. Diaphragm.              |                         |                          |

## Section 2-A

### VALVE CONTROL SYSTEM—General description

The system consists of a diaphragm control valve connected by hoses between the inlet manifold and the engine crankcase. The crankcase outlet connection incorporates an oil separator to prevent oil being pulled over with the vapours leaving the crankcase. On four-cylinder engines a filtered, restricted orifice ( $\frac{9}{16}$  in. diameter) in the oil filler cap provides a supply of fresh air into the crankcase as vapours are withdrawn by inlet manifold depression. Six-cylinder engines are fitted with a standard oil filler cap and a tube connected between the rocker cover oil filler tube and the air intake filter provides the supply of fresh air to the engine. The control valve diaphragm varies the opening to the inlet manifold according to the depression or pressure acting on it. With a decrease in manifold depression or when the crankcase obtains a positive pressure the diaphragm opens the valve allowing the crankcase vapours to be drawn into the inlet manifold. During conditions of high manifold depression, e.g. low engine speeds or loads, the diaphragm closes the valve and restricts the flow into the inlet manifold, thus preventing a leaning-off of the air/fuel mixture to the cylinders.

## Section 2-B

### VALVE CONTROL SYSTEM—Testing

- (1) Warm up the engine to normal operating temperature.

- (2) With the engine running at idling speed remove the oil filler cap.
  - (a) A rise in engine speed, the change being audibly noticeable, indicates that the control valve is functioning correctly.
  - (b) No rise in speed, service the control valve.

## Section 2-C


### VALVE CONTROL SYSTEM—Servicing

#### Oil filler cap (four-cylinder engines only)

- (1) Renew every 12,000 miles or 12 months.

#### Control valve

- (2) Disconnect the hoses and renew the valve assembly, or clean as follows:
  - (a) Remove the spring clip and withdraw the cover plate, diaphragm, metering valve and spring.
  - (b) Clean all metal parts with a solvent (trichloroethylene, fuel, etc.). **Do not use an abrasive.** If deposits are difficult to remove, immerse in boiling water before applying the solvent.
  - (c) Clean the diaphragm with a detergent or methylated spirit (denatured alcohol).
  - (d) Examine the parts thoroughly for wear or damage, and renew where necessary.
  - (e) Reassemble the valve ensuring that the metering valve fits correctly in its guides and the diaphragm is correctly seated.
  - (f) Refit the valve and check its operation.



DO926

Fig. 2

Carburettor control system

- |                   |                                    |
|-------------------|------------------------------------|
| 1. Oil separator. | 3. Carburettor chamber connection. |
| 2. Breather hose. | 4. Filtered filler cap.            |

## Section 2-D

### CARBURETTER CONTROL SYSTEM

#### Description


With this system the engine breather outlet is connected by hoses to the controlled depression chamber; the chamber between the piston and the throttle disc valve, of the carburettor(s). Engine fumes and blow-by gases are drawn from the crankcase by the depression in this chamber, through an oil separator incorporated in the engine outlet connection, and from there to the inlet manifold. Fresh air is supplied to the engine

through the combined oil filler cap and filter (four-cylinder engines) or through the air intake filter (six-cylinder engines).

#### Servicing (Not applicable to vehicles equipped with evaporative loss control systems)

The oil filler cap (four-cylinder engines only) must be renewed every 12,000 miles (20000 km.) or 12 months; no other service is required.

If a failure of the system is suspected, check the hoses and connections for leaks and obstructions. An indication of a failure is loss of crankcase depression.



D1251

*Fig. 3*

*A carburettor control system with fuel evaporative loss control*

- |   |                                     |
|---|-------------------------------------|
| 1. Ventilation air intake.                | 5. Oil separator.                   |
| 2. Absorption canister.                   | 6. Breather hose.                   |
| 3. Restricted connection to rocker cover. | 7. Carburettor chamber connections. |
| 4. Sealed oil filler cap.                 |                                     |

### Section 2-E

#### **CARBURETTER CONTROL SYSTEM— with evaporative loss control**

This system incorporates most of the components of the carburettor control system, with the exception of the combined oil filler cap and filtered air intake. Its operation differs in that air for engine breathing is drawn through the filtered absorption canister of the evaporative loss control system into the engine valve rocker cover. A restrictor in the rocker cover connection reduces the air flow to ensure crankcase depression under all conditions.

Engine fumes and blow-by gases are drawn from the crankcase, through an oil separator, into the inlet manifold by the controlled depression chamber of the carburettor.

#### **Servicing**


No direct servicing of the system is required. The air intake filter pad in the absorption canister is renewed at the intervals required by the fuel evaporative loss control.

If a failure of the system is suspected, check the hoses and connections for leaks and obstruction. An indication of a failure is loss of crankcase depression.



## EXHAUST EMISSION CONTROL (Exhaust Port Air Injection)

													<i>Section</i>
Air manifold and injectors .. .. .	..	..	..	..	..	..	..	..	..	..	..	..	3-E
Air pump (four-cylinder engines) ..	..	..	..	..	..	..	..	..	..	..	..	..	3-B
Air pump (six-cylinder engines) ..	..	..	..	..	..	..	..	..	..	..	..	..	3-C
Check valve .. .. .	..	..	..	..	..	..	..	..	..	..	..	..	3-D
General description .. .. .	..	..	..	..	..	..	..	..	..	..	..	..	3-A
Gulp valve .. .. .	..	..	..	..	..	..	..	..	..	..	..	..	3-F
Limit valve (inlet manifold depression) ..	..	..	..	..	..	..	..	..	..	..	..	..	3-G



**Fig. 1**

*A typical engine emission control system layout*

- |                             |                          |                              |
|-----------------------------|--------------------------|------------------------------|
| 1. Air manifold.            | 4. Emission air cleaner. | 7. Crankcase emission valve. |
| 2. Filtered oil filler cap. | 5. Air pump.             | 8. Vacuum sensing tube.      |
| 3. Check valve.             | 6. Relief valve.         | 9. Gulp valve.               |

## Section 3-A

### GENERAL DESCRIPTION

Air is pressure-fed from an air pump via an injection manifold to the cylinder head exhaust port of each cylinder. A check valve in the air delivery pipe prevents blow-back from high pressure exhaust gases. The pump also supplies air through a gulp valve to the inlet manifold to provide air during conditions of deceleration and engine over-run.

**IMPORTANT.** The efficient operation of the system is dependent on the engine being correctly tuned. The ignition and spark plug settings, valve clearances, and carburettor adjustments given for a particular engine (see 'TUNING DATA') must be strictly adhered to at all times.

#### Air pump

The rotary vane type air pump is mounted on the front of the cylinder head and is belt driven from the water pump pulley. Provision is made for tensioning the belt.

Air is drawn into the pump through a dry-type renewable element filter. A relief valve in the pump

discharge port allows excessive air pressure at high engine speeds to discharge to the atmosphere.

#### Check valve

The check valve, fitted in the pump discharge line to the injection manifold, protects the pump from the back-flow of exhaust gases.

The valve shuts if the air pressure ceases while the engine is running; for example, if the pump drive belt should break.

#### Gulp valve

The gulp valve, fitted in the pump discharge line to the inlet manifold, controls the flow of air for leaning-off the rich air/fuel mixture present in the inlet manifold immediately following throttle closure after running at full throttle opening (i.e. engine over-run).

A sensing pipe connected between the inlet manifold and the gulp valve maintains manifold depression directly to the underside of the diaphragm and through a bleed hole to the upper side. Sudden increases in manifold depression which occur immediately following throttle closure act on the underside of the diaphragm which opens the valve and admits air to the inlet manifold. The

## EXHAUST EMISSION CONTROL

bleed hole allows the differences in depression acting on the diaphragm to equalize and the valve closes.

On some engines a restrictor is fitted in the air pump discharge connection to the gulp valve, to prevent surging when the gulp valve is operating.

### Carburetter

The carburetters are manufactured to a special exhaust emission control specification and are tuned to give optimum engine performance with maximum emission control.

A limit valve is incorporated in the carburetter throttle disc which limits the inlet manifold depression ensuring that under conditions of high inlet-manifold depression the mixture entering the cylinders is at a combustible ratio.

## Section 3-B

### AIR PUMP (four-cylinder engines)

#### Drive belt tension

When correctly tensioned, a total deflection of  $\frac{1}{2}$  in., under moderate hand pressure, should be possible at the midway point of the longest belt run between the pulleys.

To tension the belt:

- (1) Slacken the air pump mounting bolt and adjusting link bolts (see Fig. 3).
- (2) Using hand pressure only, move the pump in the required direction until the correct tension is obtained.
- (3) Tighten the mounting and adjusting bolts to a torque figure of 10 lb. ft.

#### Testing

- (1) Check the drive belt for correct tensioning.




Fig. 2

*The pressure gauge connected (four-cylinder engines)*

1. Relief valve test tool.
2. Tape used to duct air.




Fig. 3

*Air pump (four-cylinder engines)*

1. Pump mounting bolt.
2. Adjusting link bolts.

- (2) Connect a tachometer to the engine in accordance with the instrument-maker's instructions.
- (3) Disconnect the gulp valve air supply hose at the gulp valve and securely plug the hose.
- (4) Disconnect the air manifold supply hose at the check valve, and connect a pressure gauge to the hose (see Fig. 2).
- (5) Run the engine at the air pump test speed given in 'TUNING DATA': a gauge reading of not less than 2.75 lb./sq. in. should be registered.
  - (a) If a lower reading is obtained, remove, dismantle and clean the pump air cleaner. Reassemble using a new element, refit the air cleaner and repeat the test.
  - (b) If the reading is still unsatisfactory, temporarily blank off the relief valve and repeat the test; if the reading is now correct, renew the relief valve.
  - (c) If a satisfactory reading is still unobtainable, remove and service the air pump.
- (6) Stop the engine and fit a temporary air duct over the face of the relief valve. Two methods of doing this are shown in Fig. 2. The tool (1) may be fabricated from grommet (Part No. 1B 1735) and a short length of metal brake tube, or (2) by using a piece of adhesive tape to form the duct.

**DO NOT ATTEMPT TO CHECK AIR FLOW FROM THE RELIEF VALVE BY PLACING A FINGER BETWEEN THE VALVE AND THE DRIVING PULLEY.**

- (a) Start the engine and slowly increase the speed until air flow from the relief valve duct is detected, when a gauge reading of 4.5 to 6.5 lb./sq. in. should be registered.
- (b) If the relief valve fails to operate correctly, remove the pump and renew the valve.




Fig. 4

*The air pump (four-cylinder engines)*

- |                    |                             |                     |
|--------------------|-----------------------------|---------------------|
| 1. Relief valve.   | 5. Spring.                  | 9. Outlet port.     |
| 2. Inlet chamber.  | 6. Carbons.                 | 10. Port-end cover. |
| 3. Rotor.          | 7. Vane assemblies.         | 11. Inlet port.     |
| 4. Outlet chamber. | 8. Rotor bearing end plate. |                     |

## Removing

- (1) Disconnect the air hoses from the pump connections and remove the air cleaner.
- (2) Slacken the mounting and adjusting link bolts and slip the drive belt from the pump pulley.
- (3) Remove the top adjusting link bolt and the nut securing the pump mounting bolt.
- (4) Support the pump, withdraw the mounting bolt and lift the pump from the engine.

## Dismantling

- (1) Remove the four port-end cover retaining bolts and withdraw the cover.
- (2) Remove the four screws securing the rotor bearing end plate to the rotor and remove the end plate.
- (3) Lift out the vane assemblies.
- (4) Remove the carbon and spring assemblies from the rotor.

## Servicing

- (1) Wipe the interior and components of the pump clean, using a lint-free cloth.




Fig. 5

*The dimensions of the relief valve replacing tool*

- |           |              |               |
|-----------|--------------|---------------|
| A = 5 in. | B = .986 in. | C = 1.062 in. |
|           | D = .05 in.  | E = 30°.      |

- (2) Clean the vane carrier roller bearings and the rotor end plate bearing and repack the bearings with Esso 'Andok' 260 lubricant.
- (3) Inspect the vane assemblies for signs of having fouled the pump wall, and for grooving in area of contact with the carbons. Renew worn or damaged vanes.
- (4) Fit new carbons (the original springs may be reused if serviceable). Note that the slots which carry the carbon and springs are the deeper ones, and the carbons are all fitted with the chamfered edge to the inside.

## Reassembling

- (1) Reassemble the pump by reversing the dismantling procedure and noting that the underside of the heads of the rotor bearing end plate screws must be smeared with 'Locktite' before tightening.

## Refitting

- (1) Position the pump in the mounting bracket and fit, but do not tighten, the pump mounting bolt.
- (2) Screw in, but do not tighten, the adjusting link bolt.
- (3) Fit and tension the drive belt.
- (4) Reconnect the hoses and refit the air cleaner.

## Relief valve—replacing

- (1) Remove the air pump.
- (2) Remove the pump pulley.
- (3) Pass a ½-in. diameter soft metal drift through the pump discharge connection so that it registers against the relief valve, and drive the valve from the pump.



- (4) Fit a new copper seating washer to the new relief valve and enter the valve into the pump body.
- (5) Using a tool made to the dimensions shown in Fig. 5, drive the valve into the pump until the copper seating washer is held firmly, but not compressed, between the valve and the pump.
- (6) Refit the pulley and refit the air pump.

## Section 3-C

### AIR PUMP (six-cylinder engines)

#### Drive belt tension

When correctly tensioned, a total deflection of  $\frac{1}{2}$  in., under moderate hand pressure should be possible at the midway point of the longest belt run between the pulleys.

To tension the belt:

- (1) Slacken the air pump mounting bolt and adjusting link bolts (see Fig. 6).
- (2) Using hand pressure only, move the pump in the required direction until the correct tension is obtained.
- (3) Tighten the mounting and adjusting link bolts to a torque figure of 10 lb. ft.

#### Testing

Faulty operation of the air pump is indicated by excessive pump noise. If excessive noise is present and the air pump is suspected, remove the air pump drive belt and run the engine to check that the noise is not from another source. If this check shows that the air pump is excessively noisy renew the air pump assembly or proceed as follows:

- (1) Check the drive belt for correct tensioning.
- (2) Run the engine at idle speed and check the air




Fig. 6

*Air pump (six-cylinder engines)*

1. Pump mounting bolt.
2. Adjusting link bolts.




Fig. 7

*The pressure gauge connected (six-cylinder engines)*

- supply hoses and connections for leaks and for intermittent contact with other parts of the vehicle.
- (3) Connect a tachometer to the engine in accordance with the instrument maker's instructions.
- (4) Disconnect the air supply hose tee connection from its connection with the air pump discharge hose.
- (5) Connect a pressure gauge to the air pump discharge hose (see Fig. 7).
- (6) Run the engine at the air pump test speed given in 'TUNING DATA'. A gauge reading of not less than 2.75 lb./sq. in. should be registered.
  - (a) If a lower reading is obtained, remove, dismantle, and clean the pump air cleaner. Reassemble using a new element, refit the air cleaner, and repeat the test.
  - (b) If the reading is still unsatisfactory, temporarily blank off the relief valve and repeat the test; if the reading is now correct, renew the relief valve.
  - (c) If a satisfactory reading is still unobtainable the air pump assembly must be replaced.
  - (d) From idling speed, slowly increase the engine speed until air flow from the relief valve is detected, this should occur before the gauge reading exceeds 10 lb./sq. in.
  - (e) If the relief valve fails to operate correctly, remove the pump and renew the valve.
- (7) If the foregoing tests fail to remedy or locate the cause of the air pump noise renew the air pump assembly.

#### Removing

- (1) Disconnect the hoses from the pump connections and remove the air cleaner.
- (2) Slacken the mounting and adjusting link bolts and slip the drive belt from the pump pulley.
- (3) Remove the nut from the adjusting link bolt, support the pump and withdraw the bolt.
- (4) Unscrew the mounting bolt and remove the pump.




Fig. 8

*Removing the relief valve (six-cylinder engines)*

## Relief valve—replacing

- (1) Remove the air pump.
- (2) Using a gear puller and a fabricated bridge as shown in Fig. 8, withdraw the relief valve from the pump body.  
**DO NOT HOLD THE PUMP BY CLAMPING IT IN A VICE.**
- (3) Enter the new relief valve into the pump body.
- (4) With a protective plate over the valve, carefully drive the valve into the pump until its flange registers lightly on the pump body.
- (5) Insert the pressure setting plug into the relief valve, using a suitable tool, apply pressure to the centre of the plug until the legs of the plug lock under the relief valve cage.

## Section 3-D

### CHECK VALVE

#### Removing

- (1) Disconnect the air supply hose from the check valve connection.
- (2) Hold the air manifold connection to prevent it twisting and unscrew the check valve.

#### Testing

- (1) Blow through the valve, orally, in turn from each connection. Air should only pass through the valve when blown from the air supply hose connection. If air passes through when blown from the air manifold connection, renew the check valve.

**On no account may an air blast be used for this test.**

#### Refitting

- (1) Hold the air manifold connection to prevent it twisting, screw in and tighten the check valve.
- (2) Reconnect the air supply hose to the check valve.

## Section 3-E

### AIR MANIFOLD AND INJECTORS

#### Testing

- (1) Disconnect the air manifold from the cylinder head connections.
- (2) Slacken the air supply hose clip at the check valve connection.
- (3) Rotate the manifold about its connection axis until the injector connections are accessible.
- (4) Tighten the air supply hose clip.
- (5) Run the engine at idle speed and observe the flow of air from each of the manifold connection tubes. Should the flow of air from any of the connections be restricted, remove the manifold and clear the obstruction using an air blast.
- (6) With the engine running at idle speed, check that exhaust gases blow from each of the cylinder head injectors.

**IMPORTANT.**—The injectors may be free in the cylinder head and care must be taken to ensure that they are not displaced during this test.

To clear a restricted injector:

- (a) Crank engine until the exhaust valve below the injector is closed.
- (b) Using a hand drill (not power-driven), pass a  $\frac{1}{8}$ -in. drill through the injector bore, taking care that the drill does not contact the exhaust valve stem after passing through the injector. Damage may result if a power-driven drill is used.
- (c) Insert an air-blast nozzle into the injector connection to clear carbon dust from the exhaust port.




Fig. 9

*A section through the check valve*

- |                             |                           |
|-----------------------------|---------------------------|
| 1. Air manifold connection. | 4. Valve pilot.           |
| 2. Diaphragm.               | 5. Guides.                |
| 3. Valve.                   | 6. Air supply connection. |

## Section 3-F

### GULP VALVE

#### Testing

- (1) Disconnect the gulp valve air supply hose from the air pump connection.
- (2) Connect a vacuum gauge, with a tee connection to the disconnected end of the gulp valve air hose.
- (3) Start the engine and run it at idle speed.
- (4) Temporarily seal the open connection on the gauge tee and check that a zero gauge reading is maintained for approximately 15 seconds; if a vacuum is registered, renew the gulp valve. It is most important that the engine speed is not increased above idling during this test.
- (5) With the gauge tee connection temporarily sealed, operate the throttle rapidly from closed to open; the gauge should then register a vacuum. Repeat the test several times, temporarily unsealing the tee piece connection to destroy the vacuum before each operation of the throttle. If the gauge fails to register a vacuum, renew the gulp valve.

#### Removing

- (1) Disconnect the air hoses.
- (2) Unscrew the mounting screw and remove the gulp valve.




Fig. 10

The vacuum gauge connected for testing the gulp valve




Fig. 11

A section through the gulp valve

- |                              |                                    |
|------------------------------|------------------------------------|
| 1. Metering balance orifice. | 5. Inlet manifold hose connection. |
| 2. Diaphragm.                | 6. Valve.                          |
| 3. Valve spindle.            | 7. Air pump hose connection.       |
| 4. Return spring.            |                                    |

#### Refitting

- (1) Reverse the removing procedure.

## Section 3-G

### LIMIT VALVE (INLET MANIFOLD DEPRESSION)

#### Testing

- (1) Disconnect the gulp valve sensing pipe from the inlet manifold.
- (2) Connect a vacuum gauge to the sensing pipe connection on the inlet manifold.
- (3) Connect a tachometer in accordance with the instrument maker's instructions.
- (4) Warm the engine at fast idle speed until normal operating temperature is reached.
- (5) Increase the engine speed to 3,000 r.p.m. then release the throttle quickly; the vacuum gauge reading should immediately rise to between 20.5 and 22 in. Hg. If the gauge reading falls outside these limits the carburettor must be removed and the throttle disc and limit valve assembly renewed. After refitting, the carburettor must be tuned as described in Section 4-A.

## Section 3-H

### RUNNING ON CONTROL VALVE

The solenoid operated valve is connected by hoses between the adsorption canister ventilation connection of the evaporative loss control system and the inlet manifold. A third hose connected to the valve is open to atmosphere for canister ventilation while the engine is running normally. The electrical circuit of the solenoid is connected through the ignition switch and an oil pressure operated switch.

The valve is fitted to prevent prolonged running on (dieseling) which may occur when using low octane fuels.

### Operation

When the ignition is switched off the solenoid is energized through an oil pressure switch and the valve closes, shutting off the ventilation connection and opening the connection to the inlet manifold. Inlet manifold depression then acts on the fuel in the carburettor float chamber(s) to prevent fuel flow and the engine is stopped by fuel starvation.

### Testing

If the running on valve is suspected of being faulty the control electrical circuit and operation of the valve should be checked as follows:

- (1) Check the control valve line fuse.
- (2) Turn the ignition switch to the off position.
- (3) Disconnect the control valve electrical lead at the oil pressure switch.
- (4) Touch the disconnected lead to a good earth point on the vehicle. If the control electrical circuit and valve are satisfactory, the valve will be heard to operate as the control lead is earthed.




Fig. 12

*A section through the running on control valve*


- |   |                                    |
|---|------------------------------------|
| 1. Electrical terminals.                | 6. Spring.                         |
| 2. Solenoid.                            | 7. Valve spindle.                  |
| 3. Valve body.                          | 8. Primary valve.                  |
| 4. Adsorption canister hose connection. | 9. Inlet manifold hose connection. |
| 5. Air vent hose connection.            | 10. Secondary valve.               |



## SECTION 3A

### EXHAUST EMISSION CONTROL (Engine Modifications System)

Air bleed temperature compensator	..	..	..	..	..	..	..	..	..	..	..	..	Section 3A-D
Air intake	..	..	..	..	..	..	..	..	..	..	..	..	3A-C
Air intake temperature control	..	..	..	..	..	..	..	..	..	..	..	..	3A-E
General description	..	..	..	..	..	..	..	..	..	..	..	..	3A-A
Throttle damper	..	..	..	..	..	..	..	..	..	..	..	..	3A-B



**Fig. 1**

*An engine modification exhaust emission control system showing the air intake tube in the low ambient temperature operating position*

1. Air cleaner.
2. Air intake tube.

3. Manifold shroud.
4. Throttle damper.

## Section 3A-A

### GENERAL DESCRIPTION

This system incorporates modifications to a high compression ratio engine and using a carburettor manufactured to a special exhaust emission control specification.

**IMPORTANT.** The efficient operation of the system is dependent on the engine being correctly tuned. The settings given for a particular engine (see 'TUNING DATA') must be strictly adhered to at all times.

### Carburettor


The carburettor is tuned to give optimum engine performance with maximum exhaust emission control.

A limit valve is incorporated in the carburettor throttle disc which limits the inlet manifold depression ensuring that under conditions of high inlet-manifold depression the air/fuel mixture entering the cylinders is at a combustible ratio.

### Throttle damper

A damper is fitted to act on the throttle lever as it returns to the closed position ensuring a gradual closing of the throttle valve giving smooth deceleration. Provision

is made for adjusting the damping effect; the correct setting is given in 'TUNING DATA'.



**Fig. 2**

*Adjusting the throttle damper setting*

1. Throttle lever.
2. Clamp screw.

3. Feeler gauge.
4. Throttle damper.

## Air intake

In low ambient temperature conditions the intake tube of the air cleaner is positioned in a shroud formed over a section of the exhaust manifold. Air drawn through the cleaner to the carburettor is warmed by heat given off by the manifold.

In high ambient temperature conditions the air intake tube is positioned away from the manifold and air entering the carburettor is drawn into the air cleaner from the engine compartment at ambient temperature.

## Section 3A-B

### THROTTLE DAMPER

#### Adjusting

- (1) Slacken the clamp nut on the damper operating lever.
- (2) Insert a feeler gauge (see 'TUNING DATA') between the damper plunger and the operating arm.
- (3) With the carburettor throttle disc valve in the fully closed position, press the operating lever down until the plunger is fully depressed.
- (4) Hold the lever in this position and tighten the clamp nut.
- (5) Remove the feeler gauge.

## Section 3A-C

### AIR INTAKE

#### Repositioning

- (1) Slacken the intake tube securing clip.
- (2) Slacken the air cleaner wing nuts.
- (3) Withdraw the intake tube from the air cleaner and manifold shroud.
- (4) Refit the intake tube with its entry positioned adjacent to the end of the rocker cover.
- (5) Tighten the wing nuts and securing clip.

## Section 3A-D

### AIR BLEED COMPENSATOR

#### Description

An air bleed temperature compensator is fitted to some engines equipped with twin type HS carburettors required to conform with European E.C.E. or E.E.C. exhaust emission control regulations.




Fig. 3

*The air bleed temperature compensator (showing the cap type air filter components)*

- |                         |                    |
|-------------------------|--------------------|
| 1. Cap retaining screw. | 3. Filter element. |
| 2. Filter cap.          | 4. Filter base.    |

The air bleed temperature compensator is fixed to the underside of the carburettor air cleaner and consists of a bi-metal air control valve and an air filter. It is connected by hoses to the constant depression chambers, between the piston and the throttle disc valve, of the carburettors.

With an increase in engine or engine compartment air temperature, the valve will open and allow air at ambient temperature to be drawn through the air filter and into the carburettor constant depression chambers.

The controlled admission of air into the carburettor chambers reduces the velocity and volume of air passing the needles of the carburettors, causing the pistons to fall and subsequently reduce the amount of fuel supplied, thus giving a constant air/fuel mixture ratio.

#### Servicing

The air bleed temperature compensator air filter must be renewed every 12,000 miles (20000 km.) or 12 months.

- (1) Disconnect the air cleaner to carburettor hoses.
- (2) Remove the air cleaner.
- (3) *Push-on type filters:* withdraw and discard the filter.  
*Cap type filters:* unscrew the filter cover retaining screw, remove the cover, and discard the filter element. Clean the base and cover of the filter, fit a new element, refit the cover and retaining screw.
- (4) Refit the air cleaner and reconnect the hoses.

### Section 3A-E

#### AIR INTAKE TEMPERATURE CONTROL

An air intake temperature control is fitted to some engines equipped with single Type H.S. carburettors required to conform with European E.C.E. or E.C.C. exhaust emission control regulations.

The control consists of a bi-metal operated valve, fitted in the air intake of the carburettor air cleaner, and is designed to maintain the temperature of the ingoing air within predetermined limits.

When the engine is cold, air is drawn into the air cleaner from the shrouded area adjacent to the exhaust manifold. As the temperature of the air entering the air cleaner rises, the valve opens and admits cooler air at ambient temperature to mix with the hot air and maintain a constant temperature.




Fig. 4

*The air intake temperature control*


- |                                    |                             |
|------------------------------------|-----------------------------|
| 1. Air cleaner.                    | 3. Air intake tube.         |
| 2. Air intake temperature control. | 4. Exhaust manifold shroud. |

## SECTION 4

### CARBURETTERS

	<i>Section</i>
<b>Type HS Carburettors</b>	
Carburettor servicing .. .. .	4-B
Carburettor tuning—Basic .. .. .	4-A
Single carburettors	
Twin carburettors	
Carburettor tuning—Complete .. .. .	4-C
Single carburettors	
Twin carburettors	
<b>Type HIF Carburettors</b>	
Overhauling .. .. .	4-E
Tuning .. .. .	4-D





The type HS carburettor

- |                               |                               |
|-------------------------------|-------------------------------|
| 1. Jet adjusting nut.         | 4. Fast-idle adjusting screw. |
| 2. Jet locking nut.           | 5. Throttle adjusting screw.  |
| 3. Piston suction chamber.    | 6. Piston lifting pin.        |
| 7. Jet adjustment restrictor. |                               |

## Section 4-A

### CARBURETTER TUNING—BASIC

#### GENERAL

The carburetters fitted to cars equipped with engine emission control systems are balanced to provide maximum performance with maximum pollution control. Under no circumstances may they be interchanged, or parts substituted.

Tuning must be carried out with the engine emission control equipment connected and operating, and is confined to the following procedure. If the required settings cannot be obtained, the service procedure detailed under 'CARBURETTER SERVICING' must be carried out and then the carburetter tuned in accordance with the procedure given in 'CARBURETTER TUNING—COMPLETE'.

#### Tuning conditions


To ensure that the engine temperature and mixture requirements are stabilized, tuning must be carried out in accordance with the following setting cycle.

- (1) Connect a tachometer in accordance with the instrument-maker's instructions.
- (2) Warm the engine at a fast idle to normal operating temperature, preferably with the car standing in an ambient temperature of between 16 and 27° C. (60 to 80° F.). Run the engine for at least five minutes after the thermostat has opened; the

thermostat opening point can be detected by the sudden rise in temperature of the radiator header tank.

- (3) Set the engine speed at 2,500 r.p.m., at no load, and run for one minute.
- (4) Tuning operations may now be commenced and must be carried out in the shortest possible time. If the time for settings exceeds a three-minute period, open the throttle and run the engine at 2,500 r.p.m. for one minute then resume tuning. Repeat this clearing operation if further periods of three minutes are exceeded.

### SINGLE CARBURETTERS




**NOTE.**—In no case should the jet adjustment restrictor be removed or repositioned. Only mixture adjustments within the limits of the restrictor are available for tuning. If satisfactory adjustment is not obtainable within the limits of the jet adjustment restrictor refer to 'CARBURETTER SERVICING'.

- (1) Top up the piston damper with the recommended engine oil until the level is  $\frac{1}{2}$ -in. above the top of the hollow piston rod.


**NOTE.**—On dust-proofed carburetters, identified by a transverse hole drilled in the neck of the suction chambers and no vent hole in the damper cap, the oil level must be  $\frac{1}{2}$ -in. below the top of the hollow piston rod.

- (2) Check throttle control action for signs of sticking.
- (3) Check the idling speed (Tachometer) against the figure given in 'TUNING DATA'.
  - (a) If the reading is correct and the engine runs smoothly, proceed to operations (7) and (8).
  - (b) If the reading is not correct, adjust the speed by turning the throttle adjusting screw in the required direction until the correct speed consistent with smooth running is obtained, then proceed to operations (7) and (8).
  - (c) If a smooth idle at the correct speed is not obtainable by turning the throttle adjusting screw, carry out operations (4) to (8).



## CARBURETTERS



- (4) With the engine stopped, check that the piston falls freely onto the bridge, indicated by a distinct metallic click, when the lifting pin (6) is released. If not refer to 'CARBURETTER SERVICING'.




- (5) Turn the jet adjusting nut (1) to cover the full range of adjustment available within the limits of the restrictor, selecting the setting where maximum speed is recorded on the tachometer consistent with smooth running.
- (6) Readjust the throttle adjusting screw (5) to give the correct idling speed if necessary.



- (7) Check, and if necessary adjust, the mixture control wire (8) to give a free movement of approximately  $\frac{1}{16}$ -in. before it starts to pull on the jet lever (9).
- (8) Pull the mixture control knob until the linkage is about to move the carburettor jet and adjust the fast-idle screw (4) to give the engine fast-idle speed (Tachometer) given in 'TUNING DATA'.


## TWIN CARBURETTERS



*A twin-carburettor installation*

- |                             |                                |
|-----------------------------|--------------------------------|
| 1. Jet adjusting nuts.      | 4. Fast-idle adjusting screws. |
| 2. Jet locking nuts.        | 5. Throttle adjusting screws.  |
| 3. Piston/suction chambers. | 7. Jet adjustment restrictors. |

**NOTE.**—In no case should the jet adjustment restrictor be removed or repositioned. Only mixture adjustments within the limits of the restrictor are available for tuning. Balancing of twin carburetters must only be carried out with the use of an approved balancing meter. If satisfactory adjustment or balancing is not obtainable within the limits of the jet adjustment restrictor, refer to 'CARBURETTER SERVICING'.




- (1) Top up the piston damper with the recommended engine oil until the level is  $\frac{1}{2}$ -in. above the top of the hollow piston rod.


## CARBURETTORS

**NOTE.**—On dust-proofed carburettors, identified by a transverse hole drilled in the neck of the suction chambers and no vent hole in the damper cap, the oil level must be  $\frac{1}{2}$ -in. below the top of the hollow piston rod.

- (2) Check the throttle control action for signs of sticking.
- (3) Check the idling speed (Tachometer) against the figure given in 'TUNING DATA'.
  - (a) If the reading is correct and the engine runs smoothly, proceed with operations (11) to (17).
  - (b) If the reading is not correct, carry out operations (4) to (17).




- (4) Stop the engine and remove the air cleaners.
- (5) Slacken both of the clamping bolts (10) on the throttle spindle interconnections.
- (6) Disconnect the jet control interconnection by slackening the clamping bolts (11).




- (7) Restart the engine and adjust the throttle adjusting screws on **both** carburettors to give the correct idling speed as registered by the tachometer.
- (8) Using an approved balancing meter in accordance with the maker's instructions, balance the carburettors by altering the throttle adjusting screws; the idling speed obtained during this operation must be as given in 'TUNING DATA'.

- (a) If after this operation the balance is satisfactory and consistent with smooth running at the correct idle speed, proceed with operations (14) to (17).
- (b) If correct balance cannot be obtained, check the intake system for leaks (i.e. brake servos, engine emission control equipment); if still unsatisfactory, refer to 'CARBURETTER SERVICING'.
- (c) If with the carburettors correctly balanced the idling is still erratic, carry out operations (9) to (17).



- (9) Turn the jet adjusting nut (1) on both carburettors to cover the full range of adjustment available within the limits of the restrictor, selecting the setting where maximum speed is recorded on the tachometer consistent with smooth running.
- (10) Readjust the throttle adjusting screws (5) to give the correct idling speed (see 'TUNING DATA') if necessary, ensuring that both carburettors are adjusted by an equal amount.


If the correct idling speed consistent with smooth running cannot be obtained, refer to 'CARBURETTER SERVICING'.



- (11) Set the throttle interconnection clamping levers (10) so that the link pin is .012 in. away from the lower edge of the fork (see inset). Tighten the clamp bolts ensuring that there is approximately  $\frac{1}{32}$  in. end-float on the interconnection rod.



## CARBURETTORS




A.64008

- (12) With both jet levers at their lowest position, set the jet interconnection lever clamp bolts (11) so that both jets commence to move simultaneously.
- (13) Run the engine at 1,500 r.p.m. and, using the balance meter, check that the carburettors are balanced. If they are not balanced, reset the levers, rebalance at idle speed, then recheck at 1,500 r.p.m.
- (14) Check, and if necessary adjust, the mixture control wire (1) to give approximately  $\frac{1}{8}$  in. free movement before it starts to pull on the jet levers (9).
- (15) Pull the mixture control knob until the linkage is about to move the carburettor jets.
- (16) Using the carburettor balancing meter to ensure equal adjustment, turn the fast idle adjusting screws (4) to give the correct fast idling speed (see 'TUNING DATA').
- (17) Refit the air cleaners.

### Section 4-B

#### CARBURETTOR SERVICING



A66998


### Dismantling

#### Carburettors—all types

- (1) Thoroughly clean the outside of the carburettor.
- (2) Mark the relative position (12) of the suction chamber (3) and the carburettor body (13).
- (3) Remove the damper (14) and its washer (15). Unscrew the chamber retaining screws (16).
- (4) Lift off the chamber in the direction of arrow (17) without tilting.
- (5) Remove the piston spring (18).
- (6) Carefully lift out the piston assembly (19) and empty the damper oil from the piston rod (20).

#### Carburettors—fixed needle type

- (7) Remove the needle locking screw (21) and withdraw the needle (22). If it cannot easily be removed, tap the needle inwards first and then pull outwards. Do not bend the needle.



DO927


#### Carburettors—spring-loaded needle type

- (8) Remove the guide locking screw (72), withdraw the needle assembly (73), needle support guide (74) and spring (75), taking care not to bend the needle.
- (9) Withdraw the needle from the guide and remove the spring from the needle assembly.


#### Carburettors—all types

- (10) If a piston lifting pin (23) with an external spring is fitted, remove the spring retaining circlip (24) and spring (25), then push the lifting pin upwards to remove it from its guide. With the concealed spring type (6) press the pin upwards, detach the circlip (26) from its upper end, and withdraw the pin and spring downwards.
- (11) Support the moulded base of the jet (26) and slacken the screw (27) retaining the jet pick-up link (28).

## CARBURETTORS




- (12) Relieve the tension of the pick-up lever return spring (29) from the screw and remove screw and brass bush (30) (when fitted).
- (13) Unscrew the brass sleeve nut (31) retaining the flexible jet tube (32) to the float-chamber (33) and withdraw the jet assembly (26) from the carburetor body (13). Note the gland (34), washer (35), and ferrule (36) at the end of the jet tube.
- (14) Bend back the small tag on the restrictor (7) to clear the jet adjusting nut, and remove the jet adjusting nut (1), restrictor (7), and spring (37). Unscrew the jet locking nut (2) and detach the nut




and jet bearing (38). Withdraw the bearing from the nut, noting, on fixed needle carburetors only, the locking washer (39) under the shoulder of the bearing.

- (15) Note the location points (see inset, 40) of the two ends of the pick-up lever return spring (41). Unscrew the lever pivot bolt (42) together with its double-coil spring washer (43), or spacer (44). Detach the lever assembly (9) and return spring.
- (16) Note the location (see inset, 45) of the two ends of the cam lever spring (46) and push out the pivot bolt tube (47) (or tubes), taking care not to lose the spring. Lift off the cam lever (48), noting the skid washer (49) between the two levers.



- (17) Slacken and remove the bolt (50) retaining the float-chamber (33) to the carburetor body. Note the component sequence of the flexibly mounted chambers (33) and (51).
- (18) Mark (52) the location of the float-chamber lid (53). Unscrew the lid retaining screws (54) and detach the lid and its gasket (55) complete with float assembly (56).
- (19) Push out the float hinge pin (57) from the end opposite its serrations and detach the float.
- (20) Extract the float needle (58) from its seating (59) and unscrew the seating from the lid, using a wrench .338 in. across the flats. Do not distort the seating.
- (21) Close the throttle and mark (60) the relative positions of the throttle disc (61) and the carburetor flange (62). **Do not mark the throttle disc in the vicinity of the limit valve (63).**

- (22) Unscrew the two disc retaining screws (64). Open the throttle and ease out the disc from its slot in the throttle spindle (65). The disc is oval and will jam if care is not taken; store the disc in a safe place until required for reassembly.
- (23) Tap back the tabs of the tab washer (66) securing the spindle nut (67). Note the location of the lever arm (68) in relation to the spindle and carburettor body; remove the nut and detach the arm.




A6694B

## Reassembling

### Carburettors—all types

**NOTE.**—Before reassembling, examine all components for wear and damage. Renew unserviceable components, ensuring that only parts to the correct specification (see 'TUNING DATA') are used.

- (1) Examine the throttle spindle and its bearings in the carburettor body. Check for excessive play. Renew parts as necessary.
- (2) Refit the spindle to the body. Assemble the operating lever with tab washer and spindle nut, to the spindle. Ensure that when the stop on the lever is against the abutment on the carburettor body (i.e. throttle closed position) the countersunk ends of the holes in the spindle face outwards. Tighten the spindle nut and lock with the tab washer.
- (3) Insert the throttle disc in the slot in the spindle in its original position as marked. Manoeuvre the disc in its slot until the throttle can be closed, snap the throttle open and shut to centralize it in the bore of the carburettor, taking care not to damage the throttle limit valve. When assembled, the valve must be positioned at the bottom of the disc with the head of the valve towards the engine. Fit two new disc retaining screws but do not fully tighten. Check visually that the disc closes fully, and adjust




A6277

its position as necessary. With the throttle closed there must be clearance between the throttle lever and the carburettor body. Tighten the screws fully and spread their split ends just enough to prevent turning.

- (4) Examine the float needle and seating for damage. Check that the spring-loaded plunger in the end of the plastic-bodied needle operates freely.
- (5) Screw the seating into the float-chamber carefully. Do not overtighten. Replace the needle in the seating, coned end first. Test the assembly for leakage with air pressure.
- (6) Refit the float and lever to the lid and insert the hinge pin and invert the float-chamber lid. With the needle valve held in the shut-off position by the weight of the float only, there should be a  $\frac{1}{8}$  to  $\frac{3}{16}$  in. gap (arrowed) between the float lever and the rim of the float-chamber lid.
- (7) Examine the lid gasket for re-use. Assemble the gasket on the lid and refit the lid to the float-chamber in the position marked on dismantling. Tighten the securing screws evenly.
- (8) Refit the float-chamber assembly to the carburettor body and tighten the retaining bolt fully, making sure that the registers on the body and the chamber engage correctly.
- (9) Refit the piston lifting pin, spring and circlip.
- (10) Examine the piston assembly for damage on the piston rod and the outside surface of the piston. The piston assembly must be scrupulously clean. Use gasoline or methylated spirit (denatured alcohol) as a cleaning agent. **Do not use abrasives.** Wipe dry, using a clean dry cloth.
- (11) Clean inside the suction chamber and piston rod guide using gasoline or methylated spirit (denatured alcohol) and wipe dry. Refit the damper and washer. Temporarily plug the piston transfer holes (69) and fit the piston into the suction chamber. Fit a nut and screw, with a large flat washer under the head of the screw into one of the suction






chamber fixing holes, positioning the washer (70) so that it overlaps the suction chamber bore (see illustration). Check that the piston is fully home in the suction chamber and invert the assembly to allow the chamber to fall away from the piston until the piston contacts the flat washer. Check the time taken for the suction chamber to fall the full extent of the piston travel. For HS2-type carburetors of  $1\frac{1}{4}$  in. bore the time taken should be 3 to 5 seconds, and for larger carburetors 5 to 7 seconds. If these times are exceeded check the piston and suction chamber for cleanliness and mechanical damage. If after rechecking the time taken is still not within these limits, renew the suction chamber and piston assembly.

## Carburetors—fixed needle type

- (12) Refit the needle to the piston assembly (19). The lower edge of the needle shoulder (22) must be level with the bottom face of the piston rod (20).
- (13) Fit a new needle locking screw (21) and tighten. Invert the suction chamber and spin the piston assembly inside it to check for concentricity of the needle.



- (14) Check the piston key for security in the carburetor body. Refit the piston assembly to the body and replace the piston spring over the piston rod.
- (15) Fit the suction chamber and retaining screws, taking care not to wind up the spring; tighten the securing screws evenly.
- (16) Refit the jet bearing, a new locking washer, and the locking nut; do not tighten the nut.
- (17) Centralize the jet as follows:
  - (a) Enter the end of the nylon feed tube into the base of the float-chamber, without the gland or washer fitted. Loosely secure with the retaining nut.
  - (b) Feed the jet into the jet bearing; do not fit the jet nut spring, jet adjustment restrictor, or adjusting nut at this stage.
  - (c) With the carburetor positioned with its inlet flange downwards, insert the piston loading flange downwards, insert the piston loading tool into damper tube at the top of the suction chamber and screw in until fully home. Screw the tool back until the arrow, on the tool, points towards the inlet flange of the carburetor. **The tool and carburetor must remain in this position throughout the centering operation.**
  - (d) With the piston at the bottom of its travel (on the bridge), and the jet hard up against the jet bearing, slowly tighten the jet locking nut. During the tightening process ensure that the jet is not binding in its bearing when drawn in and out. If any tightness between the jet and bearing is detected, the jet locking nut must be slackened and the process repeated.
  - (e) Remove the jet loading tool.

- (18) Withdraw the jet and tube; refit the spring, restrictor and jet adjusting nut. Fit the gland and washer to the flexible tube. The end of the tube should project a minimum of  $\frac{3}{16}$  in. beyond the gland. Refit the jet and tube. Tighten the sleeve nut until the neoprene gland is compressed. Overtightening can cause leakage.


## Carburetors—spring-loaded needle type

- (19) Refit the jet bearing, fit and tighten the jet locking nut. No jet centering is required with the spring-loaded type jet needle.
- (20) Fit the jet nut spring and adjustment restrictor. Fit the jet adjusting nut and screw it up as far as possible.
- (21) Feed the jet into the jet bearing. Fit the sleeve nut, washer and gland to the end of the flexible tube. The tube must project a minimum of  $\frac{3}{16}$  in. (4.8 mm.) beyond the gland. Tighten the sleeve nut until the gland is compressed. Overtightening can cause leakage.

## CARBURETTERS

- (22) Refit the spring to the jet needle assembly, ensuring that it locates completely in the groove of the needle support.
- (23) **IMPORTANT.** Spring-loaded needles are supplied complete with shouldered spring seats; no attempt should be made to alter the position of the spring seat or convert a fixed-type needle to spring-loaded application. The raised 'pip' formed in the needle guide ensures that the needle is correctly centralized. Under no circumstances must the 'pip' be removed or repositioned.

Fit the needle assembly into its guide and fit the assembly into the piston. The lower edge of the guide (76) must be flush with the face of the piston and the guide positioned so that the etched locating mark (77) on its lower face is adjacent to and in line with the midway point between the two piston transfer holes as illustrated.



Alternative needle guides have a flat machined on the guide which must be positioned so that the guide locking screw tightens down onto the flat. If the guide is incorrectly positioned so that the locking screw has not tightened down on the flat, the head of the screw will protrude from the piston

- (24) Fit a new guide locking screw. **NOTE.**—Guide locking screws for spring-loaded needles are shorter than the needle locking screws used with fixed needles.
- (25) Check the piston key for security in the carburettor body. Refit the piston assembly to the body and place the piston spring over the piston rod.
- (26) Fit the suction chamber and retaining screws, taking care not to wind up the spring; tighten the securing screws evenly.

### *Carburetters—all types*

- (27) Refit the damper and washer.
- (28) Reassemble the pick-up lever, cam lever, cam lever spring, skid washer, and pivot bolt tube or tubes in the positions noted on dismantling.
- (29) Place the pick-up lever return spring in position over its boss and secure the lever assembly to the carburettor body with the pivot bolt. Ensure that the double-coil spring washer or spacer fits over the projecting end of the pivot bolt tube.
- (30) Register the angled end of the return spring in the groove in the pick-up lever, and hook the other end of the spring around the moulded peg on the carburettor body.
- (31) Fit the brass ferrule to the hole in the end of the pick-up link. Relieve the tension of the return spring and fit the link to the jet with its retaining screw. When finally tightening the screw, support the moulded end of the jet.
- (32) Without removing the suction chamber, screw the jet adjusting nut until the top face of the jet is flush with the bridge of the carburettor.
- (33) Turn down the jet adjusting nut to the initial jet setting given in 'TUNING DATA'.
- (34) Refit the carburettor(s) to the engine, following the instructions given in the relevant vehicle Workshop Manual.

Tune the carburetters in accordance with the instructions given in 'CARBURETTER TUNING—COMPLETE'.

## CARBURETTERS


### Section 4-C

#### CARBURETTER TUNING—COMPLETE

The following instructions apply only to new carburetors or carburetors which have been serviced as described in 'CARBURETTER SERVICING'.

The tuning must be carried out with the engine emission control equipment connected and operating.


#### SINGLE CARBURETTORS



*The type HS carburetor*

- |                               |                               |
|-------------------------------|-------------------------------|
| 1. Jet adjusting nut.         | 4. Fast-idle adjusting screw. |
| 2. Jet locking nut.           | 5. Throttle adjusting screw.  |
| 3. Piston suction chamber.    | 6. Piston lifting pin.        |
| 7. Jet adjustment restrictor. |                               |

#### Initial setting



- (1) Disconnect the mixture control (choke) wire if fitted.
- (2) Unscrew the fast-idle screw (4) until it is well clear of the cam.
- (3) Unscrew the throttle adjusting screw (5) until it is just clear of its stop and the throttle is closed.


- (4) Set the throttle adjusting screw one full turn open.
- (5) The jet adjusting nut must not be altered at this stage as it will be initially set to a datum setting at the factory or during the carburetor servicing procedure.

#### Tuning conditions

To ensure that the engine temperature and mixture requirements are stabilized, tuning must be carried out in accordance with the following setting cycle.

- (1) Connect the tachometer and an approved exhaust gas analyser in accordance with the instrument-maker's instructions.
- (2) Warm the engine at a fast idle to normal operating temperature preferably with the car standing in an ambient temperature of between 16 and 27° C. (60 to 80° F.). Run the engine for at least five minutes after the thermostat has opened; the thermostat opening point can be detected by the sudden rise in temperature of the radiator header tank.
- (3) Set the engine speed at 2,500 r.p.m., at no load, and run for one minute.
- (4) Tuning operations may now be commenced and must be carried out in the shortest possible time. If the time for settings exceeds a three-minute period, open the throttle and run the engine at 2,500 r.p.m. for one minute then resume tuning. Repeat this clearing operation if further periods of three minutes are exceeded.

#### Tuning procedure



- (1) Top up the piston damper with the recommended engine oil until the level is  $\frac{1}{2}$  in. above the top of the hollow piston rod.




**NOTE.**—On dust-proofed carburetters, identified by a transverse hole drilled in the neck of the suction chambers and no vent hole in the damper cap, the oil level must be  $\frac{1}{2}$  in. below the top of the hollow piston rod.

- (2) Warm up the engine as described in 'Tuning conditions'.

Turn the throttle adjusting screw until the idling speed given in 'TUNING DATA' is obtained.


- (3) During the following procedure, just before the readings of the tachometer and exhaust gas analyser are taken gently tap the neck of the suction chamber with a light non-metallic instrument (e.g. a screwdriver handle).

Turn the jet adjusting nut up to weaken, down to richen, until the fastest speed is recorded on the tachometer. Turn the jet adjusting nut very slowly up (weaken) until the engine speed just commences to fall, then turn the nut one flat down (rich). Check the idling speed against the figure given in 'TUNING DATA', and adjust if necessary using the throttle adjusting screw.




- (4) Using the exhaust gas analyser, check that the percentage CO reading is within the limits given in 'TUNING DATA'.

If the reading falls outside the limits given, reset the jet adjusting nut by the minimum amount necessary to bring the reading just within the limits. If an adjustment exceeding two flats is required to achieve this the test equipment should be checked for correct calibration.




- (5) Hold the jet adjusting nut (1) to prevent it turning, and rotate the adjustment restrictor (7) round the nut until the vertical tag contacts the carburettor body on the left-hand side when viewed from the air cleaner flange (see illustration). In this position, bend the small tag on the adjustment restrictor down so that the restrictor locks to the nut and will follow its movements.
- (6) Paint the small tag of the jet adjusting nut restrictor and the adjacent flat of the jet nut to identify the locking position.



- (7) Reconnect the mixture control wire (8) with approximately  $\frac{1}{16}$  in. free movement before it starts to pull on the jet lever (9).
- (8) Pull the mixture control knob until the linkage is about to move the carburettor jet and adjust the fast-idle screw (4) to give the engine fast-idle speed.
- (9) Check and if necessary adjust the throttle damper setting—if fitted (see 'TUNING DATA').


## TWIN CARBURETTERS




### A twin-carburettor installation

- |                             |                                |
|-----------------------------|--------------------------------|
| 1. Jet adjusting nuts.      | 4. Fast-idle adjusting screws. |
| 2. Jet locking nuts.        | 5. Throttle adjusting screws.  |
| 3. Piston/suction chambers. | 7. Jet adjustment restrictors. |

### Initial settings



- (1) Slacken both clamping bolts (10) on the throttle spindle interconnections.
- (2) Disconnect the jet control interconnection by slackening the clamping bolts (11).
- (3) Disconnect the mixture control wire if fitted.




- (4) Unscrew the fast-idle screw (4) on both carburetters until they are well clear of the cams.
- (5) Unscrew the throttle adjusting screw (5) on both carburetters until they are just clear of their stops and the throttles are closed.
- (6) Set the throttle adjustment screws on both carburetters half a turn open.
- (7) The jet adjusting nuts must not be altered at this stage as they will be initially set to a datum setting either at the factory or during the carburettor servicing procedure.

### Tuning conditions

To ensure that the engine temperature and mixture requirements are stabilized, tuning must be carried out in accordance with the following setting cycle.

- (1) Connect a tachometer and an approved exhaust gas analyser in accordance with the instrument-maker's instructions.
- (2) Warm the engine at a fast idle to normal operating temperature preferably with the car standing in an ambient temperature of between 16 and 27° C. (60 to 80° F.). Run the engine for at least five minutes after the thermostat has opened; the thermostat opening point can be detected by the sudden rise in temperature of the radiator header tank.
- (3) Set the engine speed at 2,500 r.p.m., at no load, and run for one minute.
- (4) Tuning operations may now be commenced and must be carried out in the shortest possible time. If the time for settings exceeds a three-minute period, open the throttle and run the engine at 2,500 r.p.m. for one minute then resume tuning. Repeat this clearing operation if further periods of three minutes are exceeded.

### Tuning procedure







## CARBURETTERS

- (1) Top up the piston damper with the recommended engine oil until the level is  $\frac{1}{2}$  in. above the top of the hollow piston rod.

**NOTE.**—On dust-proofed carburetters, identified by a transverse hole drilled in the neck of the suction chambers and no vent hole in the damper cap, the oil level must be  $\frac{1}{2}$  in. below the top of the hollow piston rod.




- (2) Warm up the engine as described in 'TUNING CONDITIONS.'
- (3) Turn the throttle adjusting screw on both carburetters until the idling speed given in 'TUNING DATA' is obtained.
- (4) Using an approved balancing meter in accordance with the maker's instructions, balance the carburetters by altering the throttle adjusting screws; the idling speed obtained during this operation must be as given in 'TUNING DATA'.



- (5) During the following procedure, just before the readings of the tachometer and exhaust gas analyser are taken, gently tap the neck of each suction chamber with a light non-metallic instrument (e.g. a screwdriver handle).

Turn the jet adjusting nut (1) on both carburetters up to weaken, down to richen, the same amount until the fastest speed is recorded on the tachometer.


Turn both adjusting nuts very slowly up (weaken) until the engine speed just commences to fall, then turn both adjusting nuts one flat down (rich).



Check the idling speed against the figure given in 'TUNING DATA', and adjust if necessary by altering both throttle adjusting screws, each by the same amount. Using the balancing meter, check that the carburetters are balanced.


- (6) Using the exhaust gas analyser, check that the percentage CO reading is within the limits given in 'TUNING DATA'.

If the reading falls outside the limits given, reset both jet adjusting nuts by the minimum amount necessary to bring the reading just within the limits. If an adjustment exceeding two flats is required to achieve this the test equipment should be checked for correct calibration.




- (7) Hold the jet adjusting nut (1) on each carburetter, to prevent it turning, and rotate the adjustment restrictor (7) round the nut until the vertical tag contacts the carburetter body on the left-hand side when viewed from the air cleaner flange (see illustration). In this position, bend the small tag on the adjustment restrictor down so that the restrictor locks to the nut and will follow its movements.

- (8) Paint the small tag of the jet adjusting nut restrictor and the adjacent flat of the jet nut to identify the locking position.
- (9) Set the throttle interconnection clamping levers (10) in accordance with the instructions given in the relevant vehicle Workshop Manual, so that a clearance exists between the link pin and the lower edge of the fork (see inset). Tighten the clamp bolts ensuring that there is approximately  $\frac{1}{8}$  in. end float on the interconnection rod.



- (10) With both jet levers at their lowest position, set the jet interconnection lever clamp bolts (11) so that both jets commence to move simultaneously.

Run the engine at 1,500 r.p.m. and, using the balance meter, check that the carburetters are balanced.



A.6400B

- (11) Reconnect the mixture control wire (8) with approximately  $\frac{1}{8}$  in. free movement before it starts to pull on the jet levers (9).
- (12) Pull the mixture control knob until the linkage is about to move the carburetter jets.
- (13) Using the carburetter balancing meter to ensure equal adjustment, turn the fast-idle adjusting screws (4) to give the correct fast idling speed (see 'TUNING DATA').
- (14) Refit the air cleaners.

## Section 4-D

### TYPE HIF CARBURETTERS—TUNING (Fitted to MGB from 1972 Model Year)

#### General

The carburetters fitted to cars equipped with engine emission control systems are balanced to provide engine performance with pollution control. Under no circumstances may they or their components be interchanged or substituted with normal carburetters.


Tuning must be carried out with the engine emission control equipment connected and operating.

**IMPORTANT.**—Before servicing or tuning a carburetter in an endeavour to rectify poor engine performance, make sure that the maladjustment or fault is not from another source by checking the following:

- Valve clearance
- Spark plug condition
- Contact breaker (dwell angle)
- Ignition timing and advance
- Presence of air leaks into the induction system

#### Single and twin carburetters

- (1) Remove the air cleaner(s).
- (2) Check the throttle for correct operation and signs of sticking.
- (3) Unscrew the throttle adjusting screw (both screws on twin carburetters) until it is just clear of the throttle lever, with the throttle closed, then turn the screw clockwise two full turns.
- (4) Raise the piston of each carburetter with the lifting pin and check that it falls freely onto the bridge when the pin is released. If the piston shows any tendency to stick, the carburetter must be serviced.
- (5) Lift and support the piston clear of the bridge so that the jet is visible; if this is not possible due to the installed position of the carburetter, remove the suction piston chamber.
- (6) Turn the jet adjusting screw anti-clockwise until the jet is flush with the bridge or as high as possible without exceeding the bridge height. Ensure that both jets on twin carburetters are in the same relative position to the bridge of their respective carburetters.
- (7) Check that the needle guide(s) is flush with the bottom of the piston groove.
- (8) Turn the jet adjusting screw two turns clockwise (both screws on twin carburetters).
- (9) Turn the fast idle adjusting screw anti-clockwise (both screws on twin carburetters) until it is well clear of the cam.
- (10) Refit the suction piston chamber if it has been removed and, using the lifting pin, check that the piston falls freely onto the bridge.
- (11) Top up the piston damper reservoir(s) with a recommended oil until the level is  $\frac{1}{2}$  in. (13 mm.) above the top of the hollow piston rod.



- (12) Connect a reliable tachometer to the engine in accordance with the instrument manufacturer's instructions.
- (13) Start the engine and run it at a fast idle speed until it attains normal running temperature, then run it for a further five minutes.
- (14) Increase the engine speed to 2,500 r.p.m. for thirty seconds.
- (15) Connect an approved exhaust gas analyser to the engine in accordance with the instrument manufacturer's instructions.



**NOTE.**—Tuning can now commence. If the correct setting cannot be obtained within three minutes, increase the engine speed to 2,500 r.p.m. for thirty seconds and then recommence tuning. Repeat this clearing operation at three-minute intervals until tuning is completed.

## Single carburettors

- (16) Adjust the throttle adjusting screw until the correct idle speed (see '**TUNING DATA**' and/or Vehicle Emission Control Information Label) is obtained.

**NOTE.**—During the following procedure, just before the readings of the tachometer and exhaust gas analyser are taken, gently tap the neck of the suction chamber with a light-metallic instrument (e.g. a screwdriver handle).

- (17) Turn the jet adjusting screw, clockwise to enrich or anti-clockwise to weaken, until the fastest speed is indicated on the tachometer; turn the screw anti-clockwise until the engine speed just commences to fall. Turn the screw clockwise very slowly the minimum amount until the maximum speed is regained.
- (18) Check the idle speed, and re-adjust it as necessary with the throttle adjusting screw to obtain the correct setting.
- (19) Using the exhaust gas analyser, check that the percentage CO reading is within the limits given in '**TUNING DATA**' and/or Vehicle Emission Control Information Label. If the reading falls outside the limits given, reset the jet adjusting screw by the minimum amount necessary to bring the reading just within the limits. If an adjustment exceeding half a turn of the adjusting screw is required to achieve this, the carburettor must be removed and overhauled.
- (20) With the fast idle cam against its return stop, check that a  $\frac{1}{16}$  in. (1.5 mm.) free movement of the mixture control (choke) cable exists before the cable moves the cam.
- (21) Pull out the mixture control (choke) until the arrow marked on the cam is positioned under the fast idle adjusting screw.
- (22) Turn the fast idle adjusting screw clockwise until the correct fast idle speed (see '**TUNING DATA**' and/or Vehicle Emission Control Information Label) is obtained.
- (23) Refit the air cleaner.







## CARBURETTERS

### Twin carburetters

- (24) Slacken both clamping bolts on the throttle spindle interconnections.
- (25) Slacken both clamping bolts on the cold start interconnections.





- (26) Using an approved balancing meter in accordance with the maker's instructions, balance the carburetors by altering the throttle adjusting screws until the correct idle speed and balance is achieved.



**NOTE.**—During the following procedure, just before reading the tachometer and exhaust gas analyser, gently tap the neck of each suction chamber with a non-metallic instrument (e.g. a screwdriver handle).

- (27) Turn the jet adjusting screw on both carburettors clockwise to enrich or anti-clockwise to weaken, by the same amount until the fastest speed is registered on the tachometer; turn both screws anti-clockwise until the engine speed just commences to fall. Turn both screws very slowly clockwise by the minimum amount until the maximum speed is regained.
- (28) Using the exhaust gas analyser, check that the percentage CO reading is within the limits given in 'TUNING DATA' and/or Vehicle Emission Control Information Label. If the reading falls outside the limits given, reset both jet adjusting screws by the minimum amount necessary to bring the readings just within the limits. If an adjustment exceeding half a turn is required to achieve this the carburettors must be removed and overhauled.
- (29) Set the throttle interconnection clamping levers, in accordance with the instructions given in the relevant vehicle Workshop Manual, so that a clearance exists between the link pin and the lower edge of the fork. Tighten the clamp bolts, ensuring that there is approximately  $\frac{1}{32}$  in. end-float on the interconnection rod.
- (30) Run the engine at 1,500 r.p.m. and check the throttle linkage for correct connection by re-checking the carburettor balance.
- (31) With the fast idle cams of both carburettors against their respective stops, set the cold start interconnections so that both cams begin to move simultaneously.
- (32) With the fast idle cams against their stops check that a  $\frac{1}{16}$  in. (1.5 mm.) free movement of the mixture control (choke) cable exists before the cable moves the cams.
- (33) Pull out the mixture control (choke) until the arrow marked on the cam is positioned under the fast idle adjusting screw of each carburettor.
- (34) Using the balancing meter to ensure equal adjustment, turn the fast idle adjusting screws to give the correct fast idle speed (see 'TUNING DATA' and/or Vehicle Emission Control Information Label).
- (35) Refit the air cleaners.




## Section 4-E

### TYPE HIF CARBURETTORS—OVERHAULING (Fitted to MGB from 1972 Model Year)

#### Dismantling


- (1) Thoroughly clean the outside of the carburettor.
- (2) Remove the piston damper and its washer.
- (3) Unscrew the suction piston chamber retaining screws and remove the identity tag.
- (4) Lift the chamber vertically from the body without tilting it.
- (5) Remove the piston spring, lift out the piston assembly and empty the oil from the piston rod.
- (6) Unscrew the needle guide locking screw.
- (7) Withdraw the needle, guide and spring.



- (8) Mark the bottom cover-plate and body to ensure correct reassembly, unscrew the retaining screws and remove the cover complete with sealing ring.
- (9) Remove the jet adjusting screw complete with 'O' ring.
- (10) Remove the jet adjusting lever retaining screw and spring.
- (11) Withdraw the jet complete with adjusting lever and disengage the lever.
- (12) Remove the float pivot spindle and fibre washer.
- (13) Withdraw the float.
- (14) Remove the needle valve and unscrew the valve seat.
- (15) Unscrew the jet bearing locking nut and withdraw the bearing complete with fibre washer.

## CARBURETTORS

- (16) Note the location of the ends of the fast idle cam lever return spring.
- (17) Unlock and remove the cam lever retaining nut and locking washer.
- (18) With the return spring held towards the carburettor body, prise off the cam lever and remove the return spring.
- (19) Unscrew the starter unit retaining screws and remove the cover-plate.
- (20) Withdraw the starter unit assembly and remove its gasket.
- (21) Withdraw the valve spindle and remove the 'O' ring, seals and dust cap.
- (22) Note the location and loading of the ends of the throttle lever return spring and remove the spring.
- (23) Unlock and remove the nut and tab washer retaining the throttle levers.
- (24) Remove the throttle lever and throttle actuating lever.
- (25) Remove the throttle disc retaining screws.
- (26) Open the throttle; note that the throttle disc is oval, and carefully withdraw the disc from the throttle spindle. Do not damage the over-run valve.
- (27) Withdraw the throttle spindle and remove its seals.




INAI27

### INSPECTION

- (28) Examine the throttle spindle and its bearings in the carburettor body; check for excessive play, and renew parts as necessary.
- (29) Examine the float needle and seating for damage and excessive wear; renew if necessary.
- (30) Examine all rubber seals and 'O' rings for damage deterioration; renew as necessary. The cover-plate sealing ring must be renewed.
- (31) Check condition of all fibre washers and gaskets renew as necessary.
- (32) Clean the inside of the suction chamber and piston rod guide with fuel or methylated spirit (denatured alcohol) and wipe dry. Abrasives must not be used.
- (33) Examine the carburettor body for cracks and damage and for security of the brass connections and the piston key.

**NOTE.**—It is only necessary to carry out the following timing check if the cause of the carburettor malfunction which necessitated the dismantling has not been located.

- (34) Temporarily plug the piston transfer holes.
- (35) Fit the piston into the chamber without its spring.
- (36) Fit a nut and screw, with a large flat washer under the screw head, into one of the suction chamber fixing holes, positioning the washer so that it overlaps the chamber bore.
- (37) Fit the damper and washer.
- (38) Check that the piston is fully home in the chamber invert the assembly to allow the chamber to fall away until the piston contacts the washer.




I NC 204B




- (39) Check the time taken for the chamber to fall the full extent of the piston travel. For HIF carburettors  $1\frac{1}{2}$  in. (38 mm.) bore the time taken should be 4 to 6 seconds; for HIF6  $1\frac{3}{4}$  in. (44.5 mm.) bore the time taken should be 5 to 7 seconds.
- (40) If the times are exceeded, check the piston and chamber for cleanliness and damage. If after re-checking the time is still not within these limits, renew the chamber and piston assembly.

## Reassembling


- (41) Reverse the procedure in 1 to 28, noting the following:
  - (a) The throttle spindle must be fitted with the threaded end at the piston lifting pin side of the body.
  - (b) Fit the throttle disc so that the over-run valve is at the top of the bore and its spring towards the inside when the throttle is closed.
  - (c) New throttle disc retaining screws must be used when refitting the disc. Ensure that the throttle disc is correctly positioned and closes correctly before tightening and locking the retaining screw.
  - (d) Position the throttle spindle end seals just below the spindle housing flange.
  - (e) The starter unit valve is fitted with the cut-out towards the top retaining screw hole, and its retaining plate is positioned with the slotted flange towards the throttle spindle.
  - (f) After fitting the float and valve, invert the carburetter so that the needle valve is held in the shut position by the weight of the float only. Check that the point indicated on the float (see illustration) is  $0.04 \pm 0.02$  in. ( $1.0 \pm 0.5$  mm.) below the level of the float chamber face. Adjust the float position by carefully bending the arm.
  - (g) Check that the small diameter of the jet adjusting screw engages the slot in the adjusting lever and set the jet flush with the bridge of the body.
  - (h) Use a new retaining screw when refitting the needle and ensure that the needle guide etch mark aligns correctly with the piston transfer holes (see illustration). After fitting the needle assembly, check that the shoulder of the needle aligns the full face of the piston.



41(f)



41(h)



INA123



## SECTION 5

## EVAPORATIVE LOSS CONTROL

											Section
Adsorption canister .. .. .	..	..	..	..	..	..	..	..	..	..	5-B
Fuel line filter .. .. .	..	..	..	..	..	..	..	..	..	..	5-C
General description .. .. .	..	..	..	..	..	..	..	..	..	..	5-A
Leak testing .. .. .	..	..	..	..	..	..	..	..	..	..	5-D




Fig. 1

*A typical evaporative loss control system, with inset showing the arrangement of a separation tank and capacity-limiting fuel tank*

- |  |   |   |
|--|---|---|
| <ul style="list-style-type: none"> <li>1. Fuel tank.</li> <li>2. Sealed fuel filler cap.</li> <li>3. Expansion/vapour line.</li> <li>4. Expansion tank.</li> <li>5. Vapour pipe.</li> <li>6. Fuel pipe.</li> </ul> | <ul style="list-style-type: none"> <li>7. Separation tank.</li> <li>8. Adsorption canister.</li> <li>9. Purge line.</li> <li>10. Restricted connection.</li> <li>11. Air vent.</li> <li>12. Fuel pump.</li> </ul> | <ul style="list-style-type: none"> <li>13. Fuel line filter.</li> <li>14. Breather pipe.</li> <li>15. Oil separator.</li> <li>16. Sealed oil filler cap.</li> <li>17. Capacity limiting tank.</li> <li>18. Air lock bleed.</li> </ul> |
|--|---|---|

## Section 5-A

### GENERAL DESCRIPTION

The system is designed to collect fuel vapour evaporated from the fuel in the fuel tank, and on some twin carburettor cars from the fuel in the carburettor float-chambers. The vapour is stored in an adsorption canister while the engine is stopped, and then after the engine is restarted, passed through the crankcase emission control system to the combustion chambers. While the car is being driven the vapours are drawn directly to the crankcase emission control system.

Ventilation tubes on the fuel tank ensure that vapours are vented through the control system when the car is parked on other than a level surface.

To prevent spillage of fuel by displacement due to expansion, sufficient capacity is provided in the expansion tank to accommodate the amount of fuel from a full tank which would be displaced by a high temperature rise.

By the positioning of the expansion tank connections, or by the inclusion of a small separation tank in the vapour line, liquid fuel is prevented from being carried with the vapour to the storage canister.

**IMPORTANT.** The fuel and oil filler caps seal the system, and it is essential for its efficient function that they are correctly refitted after removal.

### Adsorption canister

The adsorption or vapour storage canister mounted in the engine compartment contains activated charcoal (carbon) granules. Filter pads are fitted at both sides of the charcoal to filter incoming ventilating air and to prevent the granules from leaving the canister through the purge line. The ventilation air filter pads on canisters fitted prior to 1973 models, required renewing every 12,000 miles, the later sealed type canisters are renewed complete every 24,000 miles. Vapour tubes from the fuel



## EVAPORATIVE LOSS CONTROL

tank and carburettor float-chambers and the purge line from the engine breather system are connected to the ports on the top of the canister. The port on the bottom section provides a connection for the ventilating air tube.

Fuel vapour entering the canister through the vapour tubes is adsorbed and held by the charcoal. When the engine is started, air is drawn by the crankcase emission control system, through the ventilation tube and into the canister. As the air passes over the charcoal granules the vapours are given up and are carried with the air through the crankcase emission system to the combustion chambers.




Fig. 3

*The adsorption canister*

- |                             |                          |
|-----------------------------|--------------------------|
| 1. Vapour pipe connections. | 7. Canister.             |
| 2. Purge pipe connection.   | 8. Gauze.                |
| 3. Spring.                  | 9. Retainer.             |
| 4. Gauze.                   | 10. Filter pad.          |
| 5. Filter pad.              | 11. Air vent connection. |
| 6. Charcoal granules.       | 12. End cap.             |

### Fuel expansion

Two methods are used to ensure that sufficient space is available to accommodate fuel displaced by expansion due to high ambient temperatures. The method used on the Austin America is by fitting an additional tank into which the displaced fuel flows when the volume of the fuel exceeds that of the fuel tank. The MGB and MG Midget use an air lock chamber in the fuel tank which prevents the tank being completely filled with fuel, there-




Fig. 2

*The early type adsorption canister air filter pad*

- |                   |                            |
|-------------------|----------------------------|
| 1. Air vent tube. | 4. Canister securing clip. |
| 2. Vapour pipes.  | 5. End cap.                |
| 3. Purge pipe.    | 6. Air filter pad.         |

by ensuring that sufficient space is always available for expansion.

### Fuel line filter

On some models an additional renewable filter is fitted in the main fuel line as an added safeguard against foreign matter causing the setting of the carburettor float-chamber level to be exceeded.

### Mixture temperature compensator

On some applications a small temperature-sensitive valve is fitted adjacent to the carburettor. The valve is connected between the air cleaner and the controlled depression chamber of the carburettor.

Under conditions where fuel is entering the carburettor at high temperature, i.e. prolonged idling in high ambient temperatures, the valve opens and allows a small quantity of air to pass into the carburettor, bypassing the jet. The air leans off the mixture which has been enriched by vapours from the evaporative loss control system and by




Fig. 4

*The fuel line filter*

## EVAPORATIVE LOSS CONTROL

the increase in fuel flow through the carburetter due to the high fuel temperature.

### Section 5-B

#### ADSORPTION CANISTER

##### Renewing

The air filter fitted in the bottom section of the canister must be renewed every 12,000 miles (20,000 km.) or more frequently in dusty operating conditions (early models prior to 1973 only). The complete canister must be renewed every 24,000 miles (40,000 km.) or if at any time it should inadvertently become saturated with liquid fuel.

**WARNING.** Do not attempt to recover a saturated canister by passing compressed air through the charcoal.

- (1) Disconnect the air vent tube from the bottom of the canister.
- (2) Disconnect the vapour and purge pipes from the top of the canister.
- (3) Unscrew the securing clip screw and lift out the canister.
- (4) If the air filter pad only is being renewed:
  - (a) Unscrew the lower end cap of the canister.
  - (b) Remove and discard the filter pad.
  - (c) Clean any dirt from the cap.
  - (d) Fit the new filter pad and refit the cap.
- (5) Fit the canister ensuring that the purge pipe (from the engine rocker cover) is connected to the large centre connection on the top of the canister.

### Section 5-C

#### FUEL LINE FILTER

##### Renewing

The fuel line filter must be renewed every 12,000 miles (20,000 km.).

- (1) Check that the ignition is switched off.
- (2) Disconnect and discard the filter.
- (3) Connect the new filter.
- (4) Switch on the ignition and check the filter connections for fuel leakage.
- (5) Start the engine and recheck for fuel leakage.

### Section 5-D

#### LEAK TESTING

**NOTE.** As a preliminary check for leaks on the induction and evaporative loss control systems on cars fitted with running on control valves, temporarily block the air vent pipe of the valve while the engine is idling.

If no air leaks exist in the systems the engine will stop almost immediately; if the engine continues to run an air leak is indicated.

If a fault in the operation is suspected or components of the system other than the filters or canister have been removed and refitted, the evaporative loss control system must be pressure-tested for leaks as follows:

- (1) Check that there is at least one gallon of fuel in the fuel tank.
- (2) Switch on the ignition for one minute to prime the fuel system.
- (3) Switch off the ignition and disconnect the fuel tank ventilation pipe from its connection on the adsorption canister.
- (4) Connect a 0 to 10 lb./sq. in. pressure gauge, a Schrader valve, and a low-pressure air supply (i.e. a tyre pump) to the disconnected pipe.
- (5) Pressurize the system until 1 lb./sq. in. is registered on the gauge. **DO NOT EXCEED THIS PRESSURE AT ANY TIME.**
- (6) Check that the gauge reading is maintained for 10 seconds without falling more than .5 lb./sq. in. If the reading is not maintained, check the system for leaks commencing with the fuel filler cap and seal.
- (7) Make a visual check for fuel leakage from the tank and its connections.
- (8) Remove the fuel filler cap and check that the gauge falls to zero.
- (9) Remove the test equipment and re-make the connections.




Fig. 5

*Leak-testing the control system*

1. Fuel tank ventilation pipe.
2. Pressure gauge.
3. Schrader valve.
4. Low-pressure air supply.

## SECTION 6

### TUNING DATA

												Sheet
Austin America	..	..	..	..	..	..	..	..	..	..	..	6-2
MGC ..	..	..	..	..	..	..	..	..	..	..	..	6-3
Austin	}	1800	..	..	..	..	..	..	..	..	..	6-4
Morris												
Austin	}	Mini—998 c.c. up to 1973	..	..	..	..	..	..	..	..	..	6-5
Morris												
Austin	}	Mini—998 c.c. from 1973	..	..	..	..	..	..	..	..	..	6-6
Morris												
M.G. Midget	}	up to 1972	..	..	..	..	..	..	..	..	..	6-7
Austin-Healey Sprite												
M.G. Midget from 1972 on	..	..	..	..	..	..	..	..	..	..	..	6-8
MGB up to 1972	..	..	..	..	..	..	..	..	..	..	..	6-9
MGB from 1972 on..	..	..	..	..	..	..	..	..	..	..	..	6-10

# TUNING DATA

## MODEL: AUSTIN AMERICA

### ENGINE

Type	..	..	..	..	..	..	..	12H157, 12H185, 12H393, and 12H394
Firing order	..	..	..	..	..	..	..	1, 3, 4, 2
Capacity	..	..	..	..	..	..	..	1274.86 c.c. (77.8 cu. in.)
Compression ratio	..	..	..	..	..	..	..	8.8 : 1
Compression pressure	..	..	..	..	..	..	..	120 lb./sq. in. (8.44 kg./cm. <sup>2</sup> )
Idle speed	..	..	..	..	..	..	..	850 r.p.m.
Fast idle speed	..	..	..	..	..	..	..	1,050 r.p.m. maximum
Valve rocker clearance	..	..	..	..	..	..	..	.012 in. (.305 mm.) set cold
Stroboscopic ignition timing	..	..	..	..	..	..	..	3° B.T.D.C. at 1,000 r.p.m. (vacuum pipe disconnected)
Static ignition timing	..	..	..	..	..	..	..	T.D.C.
Timing mark location	..	..	..	..	..	..	..	Marks on flywheel, pointer on flywheel housing beneath inspection cover

### DISTRIBUTOR

Make	..	..	..	..	..	..	..	Lucas
Type	..	..	..	..	..	..	..	25D4
Serial number	..	..	..	..	..	..	..	41220 or 41264
Contact breaker gap	..	..	..	..	..	..	..	.014 to .016 in. (.35 to .40 mm.)
Rotation of rotor	..	..	..	..	..	..	..	Anti-clockwise
Dwell angle	..	..	..	..	..	..	..	57° to 63°
Condenser capacity	..	..	..	..	..	..	..	.18 to .24 mF

#### Centrifugal advance

Crankshaft degrees (vacuum pipe disconnected)	..	..	..	..	..	..	..	0° at 700 to 900 r.p.m. 12° at 1,500 to 1,700 r.p.m. 30° ± 2° at 4,500 r.p.m.
---	----	----	----	----	----	----	----	---

#### Vacuum advance

Starts	..	..	..	..	..	..	..	5 in. Hg
Finishes	..	..	..	..	..	..	..	11 in. Hg
Total crankshaft degrees	..	..	..	..	..	..	..	16° ± 2°

### SPARKING PLUGS

Make	..	..	..	..	..	..	..	Champion
Type	..	..	..	..	..	..	..	N-9Y
Gap	..	..	..	..	..	..	..	.024 to .026 in. (.62 to .66 mm.)

### IGNITION COIL

Make	..	..	..	..	..	..	..	Lucas
Type	..	..	..	..	..	..	..	LA12 (early cars) BA7 (later cars) with ballast resistor
Resistance—primary at 20° C. (68° F.)	..	..	..	..	..	..	..	3.2 to 3.4 ohms 1.43 to 1.58 ohms.

#### Consumption

Ignition on—standing	..	..	..	..	..	..	..	3 to 4 amps. 4.15 amps.
at 2,000 r.p.m.	..	..	..	..	..	..	..	1 amp. 1.9 amps.

### CARBURETTER(S)

Make	..	..	..	..	..	..	..	S.U.
Type	..	..	..	..	..	..	..	Single HS4
Specification—(manual transmission)	..	..	..	..	..	..	..	AUD 281 (fixed needle type) AUD 379 (spring-loaded needle type) or AUD 345
—(automatic transmission)	..	..	..	..	..	..	..	AUD 296 (fixed needle type) AUD 380 (spring-loaded needle type) or AUD 346
Choke diameter	..	..	..	..	..	..	..	1½ in. (38.1 mm.)
Jet size	..	..	..	..	..	..	..	.090 in. (2.28 mm.)
Needle—fixed type	..	..	..	..	..	..	..	DZ
—spring-loaded type	..	..	..	..	..	..	..	AAG
Piston spring	..	..	..	..	..	..	..	Red
Initial jet adjustment	..	..	..	..	..	..	..	13 flats from bridge
Throttle damper setting	..	..	..	..	..	..	..	.10 in. (2.54 mm.)

### EXHAUST EMISSION

#### Exhaust gas analyser reading:

At engine idle speed	..	..	..	..	..	..	..	3.5% CO (maximum)
Air pump test speed	..	..	..	..	..	..	..	1,200 r.p.m. (engine)



## TUNING DATA

### MODEL: MGC

#### ENGINE

Type	..	..	..	..	..	..	29GA
Firing order	..	..	..	..	..	..	1, 5, 3, 6, 2, 4
Capacity	..	..	..	..	..	..	2912 c.c. (177.7 cu. in.)
Compression ratio	..	..	..	..	..	..	9 : 1
Compression pressure	..	..	..	..	..	..	155 lb./sq. in. (10.9 kg./cm. <sup>2</sup> )
Idle speed (manual transmission)	..	..	..	..	..	..	850 r.p.m.
Fast idle speed (manual transmission)	..	..	..	..	..	..	1,300 to 1,400 r.p.m.
Valve rocker clearance	..	..	..	..	..	..	.015 in. (.38 mm.) set cold
Stroboscopic ignition timing	..	..	..	..	..	..	4° B.T.D.C. at 1,000 r.p.m. (vacuum pipe disconnected)
Static ignition timing	..	..	..	..	..	..	T.D.C.
Timing mark location	..	..	..	..	..	..	Marks on front cover, notch on crankshaft pulley

#### DISTRIBUTOR

Make	..	..	..	..	..	..	Lucas
Type	..	..	..	..	..	..	25D6
Serial number	..	..	..	..	..	..	41224
Contact breaker gap	..	..	..	..	..	..	.014 to .016 in. (.35 to .40 mm.)
Rotation of rotor	..	..	..	..	..	..	Anti-clockwise
Dwell angle	..	..	..	..	..	..	34° to 37°
Condenser capacity	..	..	..	..	..	..	.18 to .24 mF
Centrifugal advance							
Crankshaft degrees (vacuum pipe disconnected)	..	..	..	..	..	..	0° at 700 to 900 r.p.m. 16° at 1,500 to 1,700 r.p.m. 30° ± 2° at 4,000 r.p.m.

#### Vacuum advance

Starts	..	..	..	..	..	..	5 in. Hg
Finishes	..	..	..	..	..	..	8 in. Hg
Total crankshaft degrees	..	..	..	..	..	..	6° ± 2°

#### SPARKING PLUGS

Make	..	..	..	..	..	..	Champion
Type	..	..	..	..	..	..	N-9Y
Gap	..	..	..	..	..	..	.024 to .026 in. (.625 to .660 mm.)

#### IGNITION COIL

Make	..	..	..	..	..	..	Lucas
Type	..	..	..	..	..	..	HA12
Resistance—primary	..	..	..	..	..	..	3.1 to 3.5 ohms at 20° C. (68° F.)
Consumption							
Ignition on—standing	..	..	..	..	..	..	3.9 amps.
at 2,000 r.p.m.	..	..	..	..	..	..	1.4 amps.

#### CARBURETTER(S)

Make	..	..	..	..	..	..	S.U.
Type	..	..	..	..	..	..	Twin HS6
Specification—fixed needle type	..	..	..	..	..	..	AUD 287
—spring-loaded needle type	..	..	..	..	..	..	AUD 342
Choke diameter	..	..	..	..	..	..	1½ in. (44.4 mm.)
Jet size	..	..	..	..	..	..	.100 in. (2.54 mm.)
Needle—fixed type	..	..	..	..	..	..	KM
—spring-loaded type	..	..	..	..	..	..	BAD
Piston spring	..	..	..	..	..	..	Yellow
Initial jet adjustment	..	..	..	..	..	..	8 flats from bridge

#### EXHAUST EMISSION

Exhaust gas analyser reading:							
At engine idle speed	..	..	..	..	..	..	3% CO (maximum)
Air pump test speed	..	..	..	..	..	..	1,000 r.p.m. (engine)

## TUNING DATA

### MODEL: AUSTIN/MORRIS—1800 Mk. II

#### ENGINE

Type	..	..	..	..	..	..	..	18H359B, 18H360B, 18H361B, 18H362B, 18H363B, 18H364B
Firing order	..	..	..	..	..	..	..	1, 3, 4, 2
Capacity	..	..	..	..	..	..	..	1798 c.c. (109.8 cu. in.)
Compression ratio	..	..	..	..	..	..	..	9 : 1
Compression pressure	..	..	..	..	..	..	..	160 lb./sq. in. (11.25 kg./cm. <sup>2</sup> )
Idle speed	..	..	..	..	..	..	..	800 r.p.m.
Fast idle speed	..	..	..	..	..	..	..	1,100 to 1,200 r.p.m.
Valve rocker clearance	..	..	..	..	..	..	..	.015 in. (.38 mm.) set cold
Stroboscopic ignition timing	..	..	..	..	..	..	..	14° B.T.D.C. at 1,000 r.p.m. (vacuum pipe disconnected)
Timing mark location	..	..	..	..	..	..	..	Pointer on timing case, notch on crankshaft pulley

#### DISTRIBUTOR

Make	..	..	..	..	..	..	..	Lucas
Type	..	..	..	..	..	..	..	25D4
Serial number	..	..	..	..	..	..	..	41234
Contact breaker gap	..	..	..	..	..	..	..	.014 to .016 in. (.35 to .40 mm.)
Rotation of rotor	..	..	..	..	..	..	..	Anti-clockwise
Dwell angle	..	..	..	..	..	..	..	57° to 63°
Condenser capacity	..	..	..	..	..	..	..	.18 to .24 mF
Centrifugal advance	..	..	..	..	..	..	..	
Crankshaft degrees (vacuum pipe disconnected)	..	..	..	..	..	..	..	14° at 800 to 1,000 r.p.m. 19° at 1,400 to 1,600 r.p.m. 42° ± 1° at 6,000 r.p.m.
Vacuum advance	..	..	..	..	..	..	..	
Starts	..	..	..	..	..	..	..	4 in. Hg
Finishes	..	..	..	..	..	..	..	12 in. Hg
Total crankshaft degrees	..	..	..	..	..	..	..	16° ± 2°

#### SPARKING PLUGS

Make	..	..	..	..	..	..	..	Champion
Type	..	..	..	..	..	..	..	N-9Y
Gap	..	..	..	..	..	..	..	.024 to .026 in. (.625 to .660 mm.)

#### IGNITION COIL

Make	..	..	..	..	..	..	..	Lucas
Type	..	..	..	..	..	..	..	HA12
Resistance—primary	..	..	..	..	..	..	..	3.1 to 3.5 ohms at 20° C. (68° F.)
Consumption	..	..	..	..	..	..	..	
Ignition on—standing	..	..	..	..	..	..	..	3.9 amps.
at 2,000 r.p.m.	..	..	..	..	..	..	..	1.4 amps.

#### CARBURETTER(S)

Make	..	..	..	..	..	..	..	S.U.
Type/Specification	..	..	..	..	..	..	..	HS6/AUD 314 (manual); AUD 315 (automatic)
Choke diameter	..	..	..	..	..	..	..	1 $\frac{3}{4}$ in. (44.4 mm.)
Jet size	..	..	..	..	..	..	..	.100 in. (2.54 mm.)
Needle	..	..	..	..	..	..	..	BAJ
Piston spring	..	..	..	..	..	..	..	Yellow
Initial jet adjustment	..	..	..	..	..	..	..	12 flats from bridge

#### EXHAUST EMISSION

Exhaust gas analyser reading:	..	..	..	..	..	..	..	
At engine idle speed	..	..	..	..	..	..	..	3% CO (maximum)
Air pump test speed	..	..	..	..	..	..	..	1,000 r.p.m. (engine)

---

[illegible]

Make	..	..	..	..	..	..	Lucas
Type	..	..	..	..	..	..	25D4
Serial number	..	..	..	..	..	..	41134A to 1971; 41395 from 1972 on
Contact breaker gap	..	..	..	..	..	..	.014 to .016 in. (.35 to .40 mm.)
Rotation of rotor	..	..	..	..	..	..	Anti-clockwise
Dwell angle	..	..	..	..	..	..	57° to 63°
Condenser capacity	..	..	..	..	..	..	.18 to .24 mF
<b>Centrifugal advance</b>							
Crankshaft degrees (vacuum pipe disconnected)	..						4° at 600 to 800 r.p.m. 16° at 1,400 to 1,600 r.p.m. 24°±2° at 3,000 r.p.m.
<b>Vacuum advance</b>							
Starts	..	..	..	..	..	..	To 1971 3 in. Hg
Finishes	..	..	..	..	..	..	From 1972 on 5 in. Hg
Total crankshaft degrees	..	..	..	..	..	..	15 in. Hg 8 in. Hg 18°±2° 6°+2°

Make	..	..	..	..	..	..	..	Champion
Type	..	..	..	..	..	..	..	N-9Y
Gap	..	..	..	..	..	..	..	.024 to .026 in. (.625 to .660 mm.)

Make	..	..	..	..	..	..	..	Lucas
Type	..	..	..	..	..	..	..	LA 12
Resistance—primary	..	..	..	..	..	..	..	3.2 to 3.4 ohms at 20° C (68° F.)
<b>Consumption</b>								
Ignition on—standing	..	..	..	..	..	..	..	3 to 4 amps.
at 2,000 r.p.m.	..	..	..	..	..	..	..	1 amp.

Make	.. .. .	S.U.
Type/Specification	.. .. .	HS4/AUD 398 to 1971; AUD 548 from 1972 on
Choke diameter	.. .. .	1½ in. (38·1 mm.)
Jet size	.. .. .	·090 in. (2·28 mm.)
Needle	.. .. .	AAG
Piston spring	.. .. .	Red
Initial jet adjustment	.. .. .	11 flats from bridge
Throttle damper setting	.. .. .	·080 in. (2·03 mm.)

Exhaust gas analyser reading:  
At engine idle speed .. .. 4.5% CO (maximum)

## TUNING DATA

### MODEL: AUSTIN/MORRIS—MINI 998 c.c.—1973 Models

#### ENGINE

Type	..	..	..	..	..	..	99H
Firing order	..	..	..	..	..	..	1, 3, 4, 2
Capacity	..	..	..	..	..	..	998 c.c. (60.96 cu. in.)
Compression ratio	..	..	..	..	..	..	8.9 : 1
Compression pressure	..	..	..	..	..	..	120 lb./sq. in. (84.4 kg./cm. <sup>2</sup> )
Idle speed	..	..	..	..	..	..	850 r.p.m.
Fast idle speed	..	..	..	..	..	..	1,200 to 1,300 r.p.m.
Valve rocker clearance	..	..	..	..	..	..	.012 in. (.305 mm.) set cold
Stroboscopic ignition timing	..	..	..	..	..	..	8° B.T.D.C. at 1,500 r.p.m. (vacuum pipe disconnected)
Static ignition timing	..	..	..	..	..	..	6° B.T.D.C.
Timing mark location	..	..	..	..	..	..	Pointer on converter housing beneath inspection cover, marks on converter

#### DISTRIBUTOR

Make	..	..	..	..	..	..	Lucas
Type	..	..	..	..	..	..	25D4
Serial number	..	..	..	..	..	..	41532
Contact breaker gap	..	..	..	..	..	..	.014 to .016 in. (.35 to .40 mm.)
Rotation of rotor	..	..	..	..	..	..	Anti-clockwise
Dwell angle	..	..	..	..	..	..	57° to 63°
Condenser capacity	..	..	..	..	..	..	.18 to .24 mF

#### Centrifugal advance

Crankshaft degrees (vacuum pipe disconnected)	..	..	..	..	..	..	8° at 1,500 to 2,100 r.p.m. 18° at 2,800 to 3,400 r.p.m. 24°±2° at 5,200 r.p.m.
---	----	----	----	----	----	----	---

#### Vacuum advance

Starts	..	..	..	..	..	..	10 in. Hg
Finishes	..	..	..	..	..	..	15 in. Hg
Total crankshaft degrees	..	..	..	..	..	..	10°±2°

#### SPARKING PLUGS

Make	..	..	..	..	..	..	Champion
Type	..	..	..	..	..	..	N-9Y
Gap	..	..	..	..	..	..	.024 to .026 in. (.625 to .660 mm.)

#### IGNITION COIL

Make	..	..	..	..	..	..	Lucas
Type	..	..	..	..	..	..	LA 12
Resistance—primary	..	..	..	..	..	..	3.2 to 3.4 ohms at 20° C. (68° F.)

#### Consumption

Ignition on—standing	..	..	..	..	..	..	3 to 4 amps.
at 2,000 r.p.m.	..	..	..	..	..	..	1 amp.

#### CARBURETTER(S)

Make	..	..	..	..	..	..	S.U.
Type/Specification	..	..	..	..	..	..	HS4/AUD 618
Choke diameter	..	..	..	..	..	..	1½ in. (38.1 mm.)
Jet size	..	..	..	..	..	..	.090 in. (2.28 mm.)
Needle	..	..	..	..	..	..	ABJ
Piston spring	..	..	..	..	..	..	Red
Initial jet adjustment	..	..	..	..	..	..	11 flats from bridge
Throttle damper setting	..	..	..	..	..	..	.080 in. (2.03 mm.)

#### EXHAUST EMISSION

Exhaust gas analyser reading:

At engine idle speed	..	..	..	..	..	..	4.5% CO (maximum)
----------------------	----	----	----	----	----	----	-------------------



## TUNING DATA

### MODEL: SPRITE (Mk. IV)/MIDGET (Mk. III) Up to 1972

#### ENGINE

Type	..	..	..	..	..	..	12CD or 12CJ
Firing order	..	..	..	..	..	..	1, 3, 4, 2
Capacity	..	..	..	..	..	..	1274.86 c.c. (77.8 cu. in.)
Compression ratio	..	..	..	..	..	..	8.8 : 1
Compression pressure	..	..	..	..	..	..	120 lb./sq. in. (8.44 kg./cm. <sup>2</sup> )
Idle speed	..	..	..	..	..	..	1,000 r.p.m.
Fast idle speed	..	..	..	..	..	..	1,100 r.p.m. to 1,200 r.p.m.
Valve rocker clearance	..	..	..	..	..	..	.012 in. (.305 mm.) set cold
Stroboscopic ignition timing*	..	..	..	..	..	..	10° B.T.D.C. at 1,000 r.p.m.
Static ignition timing	..	..	..	..	..	..	4° B.T.D.C.
Timing mark location	..	..	..	..	..	..	Pointer on timing case, notch on crankshaft pulley

#### DISTRIBUTOR

Make	..	..	..	..	..	..	Lucas
Type	..	..	..	..	..	..	25D4
Serial number	..	..	..	..	..	..	41229 to 1971; 41271 from 1971 on
Contact breaker gap	..	..	..	..	..	..	.014 to .016 in. (.35 to .40 mm.)
Rotation of rotor	..	..	..	..	..	..	Anti-clockwise
Dwell angle	..	..	..	..	..	..	57° to 63°
Condenser capacity	..	..	..	..	..	..	.18 to .24 mF
Centrifugal advance							
Crankshaft degrees*	..	..	..	..	..	..	4° at 500 to 700 r.p.m. 19° at 2,300 to 2,500 r.p.m. 30° ± 2° at 4,300 r.p.m.
Vacuum advance							
Starts	..	..	..	..	..	..	5 in. Hg
Finishes	..	..	..	..	..	..	8 in. Hg
Total crankshaft degrees	..	..	..	..	..	..	6° ± 2°

#### SPARKING PLUGS

Make	..	..	..	..	..	..	Champion
Type	..	..	..	..	..	..	N-9Y
Gap	..	..	..	..	..	..	.024 to .026 in. (.625 to .660 mm.)

#### IGNITION COIL

Make	..	..	..	..	..	..	Lucas
Type	..	..	..	..	..	..	11C12
Resistance—primary	..	..	..	..	..	..	3 to 3.4 ohms at 20° C. (68° F.)
Consumption							
Ignition on—standing	..	..	..	..	..	..	3.5 to 4 amps.
at 2,000 r.p.m.	..	..	..	..	..	..	1 amp.

#### CARBURETTER(S)

Make	..	..	..	..	..	..	S.U.
Type	..	..	..	..	..	..	Twin HS2
Specification—fixed needle type	..	..	..	..	..	..	AUD 266
—spring-loaded needle type	..	..	..	..	..	..	AUD 328 to 1971; AUD 404 from 1971 on
Choke diameter	..	..	..	..	..	..	1½ in. (31.75 mm.)
Jet size	..	..	..	..	..	..	.090 in. (2.28 mm.)
Needle—fixed type	..	..	..	..	..	..	AN
—spring-loaded type	..	..	..	..	..	..	AAC
Piston spring	..	..	..	..	..	..	Blue
Initial jet adjustment	..	..	..	..	..	..	11 flats from bridge

#### EXHAUST EMISSION

Exhaust gas analyser reading:							
At engine idle speed	..	..	..	..	..	..	2.5% CO (maximum)
Air pump test speed	..	..	..	..	..	..	1,200 r.p.m. (engine)

\* Vacuum pipe disconnected.

## TUNING DATA

### MODEL: M.G. MIDGET (Mk. III) from 1972 on

#### ENGINE

Type	..	..	..	..	..	..	12V
Firing order	..	..	..	..	..	..	1, 3, 4, 2
Capacity	..	..	..	..	..	..	1274.86 c.c. (77.8 cu. in.)
Compression ratio	..	..	..	..	..	..	8 : 1
Compression pressure	..	..	..	..	..	..	120 lb./sq. in. (8.44 kg./cm. <sup>2</sup> )
Idle speed	..	..	..	..	..	..	1,000 r.p.m.
Fast idle speed	..	..	..	..	..	..	1,100 r.p.m. to 1,200 r.p.m.
Valve rocker clearance	..	..	..	..	..	..	.012 in. (.305 mm.) set cold
Stroboscopic ignition timing*	..	..	..	..	..	..	9° B.T.D.C. at 1,500 r.p.m.
Static ignition timing	..	..	..	..	..	..	T.D.C.
Timing mark location	..	..	..	..	..	..	Pointer on timing case, notch on crankshaft pulley

#### DISTRIBUTOR

Make	..	..	..	..	..	..	Lucas
Type	..	..	..	..	..	..	25D4
Serial number	..	..	..	..	..	..	1972—41369; from 1973—41400
Contact breaker gap	..	..	..	..	..	..	.014 to .016 in. (.35 to .40 mm.)
Rotation of rotor	..	..	..	..	..	..	Anti-clockwise
Dwell angle	..	..	..	..	..	..	57° to 63°
Condenser capacity	..	..	..	..	..	..	.18 to .24 mF
<b>Centrifugal advance</b>							
Crankshaft degrees*	..	..	..	..	..	..	15° at 1,800 to 2,000 r.p.m. 24° at 2,700 to 3,100 r.p.m. 36°±2° at 4,200 r.p.m.
							<i>Serial No.</i>
Vacuum advance							41369 (1972)      41400 (1973)
Starts	..	..	..	..	..	..	4 in. Hg      10 in. Hg
Finishes	..	..	..	..	..	..	9 in. Hg      15 in. Hg
Total crankshaft degrees	..	..	..	..	..	..	16°±2°      10°±2°

#### SPARKING PLUGS

Make	..	..	..	..	..	..	Champion
Type	..	..	..	..	..	..	N-9Y
Gap	..	..	..	..	..	..	.024 to .026 in. (.625 to .660 mm.)

#### IGNITION COIL

Make	..	..	..	..	..	..	Lucas
Type	..	..	..	..	..	..	11C12
Resistance—primary	..	..	..	..	..	..	3 to 3.4 ohms at 20° C. (68° F.)
<b>Consumption</b>							
Ignition on—standing	..	..	..	..	..	..	3.5 to 4 amps.
at 2,000 r.p.m.	..	..	..	..	..	..	1 amp.

#### CARBURETTER(S)

Make	..	..	..	..	..	..	S.U.
Type	..	..	..	..	..	..	Twin HS2
Specification	..	..	..	..	..	..	1972—AUD 502; from 1973—AUD 549
Choke diameter	..	..	..	..	..	..	1½ in. (31.75 mm.)
Jet size	..	..	..	..	..	..	.090 in. (2.28 mm.)
Needle	..	..	..	..	..	..	1972—AAT; from 1973—ABC
Piston spring	..	..	..	..	..	..	Blue
Initial jet adjustment	..	..	..	..	..	..	11 flats from bridge

#### EXHAUST EMISSION

Exhaust gas analyser reading:							
At engine idle speed	..	..	..	..	..	..	1972—3% CO (maximum); from 1973, 2.5% CO (maximum)
Air pump test speed	..	..	..	..	..	..	1,200 r.p.m. (engine)

\* Vacuum pipe disconnected.

# TUNING DATA

## MODEL: MGB

ENGINE					To 1971	1971
Type	..	..	..	..	18GF, 18GH, or 18GJ	18GK
Firing order	..	..	..	..	1, 3, 4, 2,	1, 3, 4, 2
Capacity	..	..	..	..	1800 c.c. (110 cu. in.)	1800 c.c. (110 cu. in.)
Compression ratio	..	..	..	..	8.8 : 1	8.8 : 1
Compression pressure	..	..	..	..	160 lb./sq. in. (11.25 kg./cm. <sup>2</sup> )	160 lb./sq. in. (11.25 kg./cm. <sup>2</sup> )
Idle speed	..	..	..	..	900 r.p.m.	900 r.p.m.
Fast idle speed	..	..	..	..	1,300 to 1,400 r.p.m.	1,300 to 1,400 r.p.m.
Valve rocker clearance	..	..	..	..	.015 in. (.38 mm.) set cold	.015 in. (.38 mm.) set cold
Stroboscopic ignition timing*	..	..	..	..	20° B.T.D.C. at 1,000 r.p.m.	15° B.T.D.C. at 1,500 r.p.m.
Static ignition timing	..	..	..	..	10° B.T.D.C.	10° B.T.D.C.
Timing mark location	..	..	..	..	Pointer on timing case, notch on crankshaft pulley	Pointer on timing case, notch on crankshaft pulley
DISTRIBUTOR						
Make	..	..	..	..	Lucas	Lucas
Type	..	..	..	..	25D4	25D4
Serial number	..	..	..	..	40897 or 41155	41339
Contact breaker gap	..	..	..	..	.014 to .016 in. (.35 to .40 mm.)	.014 to .016 in. (.35 to .40 mm.)
Rotation of rotor	..	..	..	..	Anti-clockwise	Anti-clockwise
Dwell angle	..	..	..	..	57° to 63°	57° to 63°
Condenser capacity	..	..	..	..	.18 to .24 mF	.18 to .24 mF
Centrifugal advance						
Crankshaft degrees*	..	..	..	..	10° at 400 to 600 r.p.m. 24° at 1,500 to 1,750 r.p.m. 30°±2° at 3,000 r.p.m.	10° at 900 to 1,100 r.p.m. 24° at 2,700 to 2,900 r.p.m. 30°±2° at 4,600 r.p.m.
Vacuum advance						
Starts	..	..	..	..	5 in. Hg	7 in. Hg
Finishes	..	..	..	..	13 in. Hg	13 in. Hg
Total crankshaft degrees	..	..	..	..	20°±2°	10°±2°
SPARKING PLUGS						
Make	..	..	..	..	Champion	Champion
Type	..	..	..	..	N-9Y	N-9Y
Gap	..	..	..	..	.024 to .026 in. (.625 to .660 mm.)	.024 to .026 in. (.625 to .660 mm.)
IGNITION COIL						
Make	..	..	..	..	Lucas	Lucas
Type	..	..	..	..	HA12	HA12
Resistance—primary	..	..	..	..	3.1 to 3.5 ohms at 20° C. (68° F.)	3.1 to 3.5 ohms at 20° C. (68° F.)
Consumption						
Ignition on—standing	..	..	..	..	3.9 amps.	3.9 amps.
at 2,000 r.p.m.	..	..	..	..	1.4 amps.	1.4 amps.
CARBURETTER(S)						
Make	..	..	..	..	S.U.	S.U.
Type	..	..	..	..	Twin HS4	Twin HS4
Specification—fixed needle type	..	..	..	..	AUD 265	—
—spring-loaded needle type	..	..	..	..	AUD 326	AUD 465
Choke diameter	..	..	..	..	1½ in. (38.1 mm.)	1½ in. (38.1 mm.)
Jet size	..	..	..	..	.090 in. (2.2 mm.)	.090 in. (2.2 mm.)
Needle—fixed type	..	..	..	..	FX	—
—spring-loaded type	..	..	..	..	AAE	AAL
Piston spring	..	..	..	..	Red	Red
Initial jet adjustment	..	..	..	..	14 flats from bridge	12 flats from bridge
EXHAUST EMISSION						
Exhaust gas analyser reading:						
At engine idle speed	..	..	..	..	4.5% CO (maximum)	4.5% CO (maximum)
Air pump test speed	..	..	..	..	1,000 r.p.m. (engine)	1,000 r.p.m. (engine)

\* Vacuum pipe disconnected.

## TUNING DATA

### MODEL: MGB from 1972 on

#### ENGINE

Type	..	..	..	..	..	..	..	18V
Firing order	..	..	..	..	..	..	..	1, 3, 4, 2,
Capacity	..	..	..	..	..	..	..	1800 c.c. (110 cu. in.)
Compression ratio	..	..	..	..	..	..	..	8·0 : 1
Compression pressure	..	..	..	..	..	..	..	160 lb./sq. in. (11·25 kg./cm. <sup>2</sup> )
Idle speed	..	..	..	..	..	..	..	850 r.p.m.
Fast idle speed	..	..	..	..	..	..	..	1,300 to 1,400 r.p.m.
Valve rocker clearance	..	..	..	..	..	..	..	·015 in. (·38 mm.) set cold
Stroboscopic ignition timing*	..	..	..	..	..	..	..	1972—16° B.T.D.C. at 1,500 r.p.m.; from 1973—11° B.T.D.C. at 1,500 r.p.m.
Static ignition timing	..	..	..	..	..	..	..	1972—10° B.T.D.C.; from 1973—6° B.T.D.C.
Timing mark location	..	..	..	..	..	..	..	Pointer on timing case, notch on crankshaft pulley

#### DISTRIBUTOR

Make	..	..	..	..	..	..	..	Lucas
Type	..	..	..	..	..	..	..	25D4
Serial number	..	..	..	..	..	..	..	1972—41370; from 1973—41491
Contact breaker gap	..	..	..	..	..	..	..	·014 to ·016 in. (·36 to ·41 mm.)
Rotation of rotor	..	..	..	..	..	..	..	Anti-clockwise
Dwell angle	..	..	..	..	..	..	..	57° to 63°
Condenser capacity	..	..	..	..	..	..	..	·18 to ·24 mF
<b>Centrifugal advance</b>								<i>Serial No. 41370 (1972)</i> <i>Serial No. 41491 (1973)</i>
Crankshaft degrees*	..	..	..	..	..	..	..	20° at 1,700 to 2,000 r.p.m.      16° at 1,800 to 2,250 r.p.m.
								35° at 3,300 to 3,900 r.p.m.      32° at 3,600 to 4,050 r.p.m.
								41°±2° at 4,800 r.p.m.      39°±2° at 4,800 r.p.m.
<b>Vacuum advance</b>								
Starts	..	..	..	..	..	..	..	7 in. Hg      10 in. Hg
Finishes	..	..	..	..	..	..	..	13 in. Hg      15 in. Hg
Total crankshaft degrees	..	..	..	..	..	..	..	6°±2°      10°±2°

#### SPARKING PLUGS

Make	..	..	..	..	..	..	..	Champion
Type	..	..	..	..	..	..	..	N-9Y
Gap	..	..	..	..	..	..	..	·024 to ·026 in. (·625 to ·660 mm.)

#### IGNITION COIL

Make	..	..	..	..	..	..	..	Lucas
Type	..	..	..	..	..	..	..	HA12
Resistance—primary	..	..	..	..	..	..	..	3·1 to 3·5 ohms at 20° C. (68° F.)

#### Consumption

Ignition on—standing	..	..	..	..	..	..	..	3·9 amps.
at 2,000 r.p.m.	..	..	..	..	..	..	..	1·4 amps.

#### CARBURETTER(S)

Make	..	..	..	..	..	..	..	S.U.
Type	..	..	..	..	..	..	..	Twin HIF4
Specification	..	..	..	..	..	..	..	1972—AUD 493; from 1973—AUD 550
Choke diameter	..	..	..	..	..	..	..	1½ in. (38·1 mm.)
Jet size	..	..	..	..	..	..	..	·090 in. (2·2 mm.)
Needle	..	..	..	..	..	..	..	1972—AAU; from 1973—ABD
Piston spring	..	..	..	..	..	..	..	Red
Initial jet adjustment	..	..	..	..	..	..	..	2 turns down from bridge

#### EXHAUST EMISSION







##### Exhaust gas analyser reading:

At engine idle speed	..	..	..	..	..	..	..	1972—3·5% CO (maximum); 1973—2·5% CO (maximum)
Air pump test speed	..	..	..	..	..	..	..	1,000 r.p.m. (engine)

\* Vacuum pipe disconnected.



SPEED ENGINE	TEST	COMPONENT CONDITION	READ/OBSERVE
<b>START (cranking)</b>	Cranking voltage	Battery; starting system	Voltmeter
	Cranking coil output	Coil and ignition circuit	Scope trace
	Positive crankcase ventilation/ cranking vacuum	Crankcase emission equipment	Vacuum gauge
<b>IDLING (see 'TUNING DATA')</b>	Idle speed	Carburetter idle setting	Tachometer
	Dwell	Distributor/drive; points	Dwell meter; scope
	Initial timing	Spark timing setting	Timing light
	Fuel mixture	Carburetter setting	Exhaust gas analyser
	Manifold vacuum	Engine idle efficiency	Vacuum gauge
<b>FAST IDLE (see 'TUNING DATA')</b>	Dwell variation	Distributor mechanical	Dwell meter
	Coil polarity	Ignition circuit polarity	Scope trace
	Cam lobe accuracy	Distributor cam	Scope trace
	Secondary circuit	Plugs; leads; cap; rotor	Scope trace
	Coil and condenser condition	Coil windings; condenser	Scope trace
	Breaker point condition	Points closing/opening/bounce	Scope trace
	Spark plug firing voltage	Fuel mixture; compression; plug/ rotor gaps	Scope trace
<b>ACCELERATE— DECELERATE</b>	Spark plugs under load	Spark plugs	Scope trace
	Carburetter open/close action	Carburetter	Exhaust gas analyser and vacuum gauge
<b>TURNPIKE (Maximum ignition advance speed see 'TUNING DATA')</b>	Timing advance	Distributor mech./vacuum ad- vance	Timing light/advance meter
	Maximum coil output	Coil; condenser; ignition primary	Scope trace
	Secondary circuit insulation	H.T. cables, cap, rotor	Scope trace
	Charging voltage	Regulator; cut-out	Voltmeter
	Fuel mixture	Air cleaner, carburetter	Exhaust gas analyser
	Exhaust restriction	Exhaust system	Vacuum gauge

READINGS	CHECK SEQUENCE—FAULT LOCATION	
<p>9.6 volts minimum at the battery</p> <p>17 KV. minimum</p> <p>6—10 in. Hg (crankcase ventilation operating)</p> <p>8—15 in. Hg (crankcase ventilation blanked)</p>	<p>Battery—connections/cables—starter motor—dynamo/alternator—regulator</p> <p>Ignition coil</p> <p>Hoses and connections—Oil filler cap—Valve rocker clearance—Emission valve—Gulp valve—Oil separator—Servo (if fitted)—Inlet manifold leaks—Valves or seats—Piston rings—Any air leak to crankcase</p>	 <p>Pattern 1</p>
<p>See 'TUNING DATA'</p> <p>4-cyl. : 57 to 63°; 6-cyl. : 34 to 37°. See Pattern 1 (see inset A)</p> <p>See 'TUNING DATA'</p> <p>See 'TUNING DATA'</p> <p>12 in. Hg minimum (engine fully run in)</p>	<p>Carburetter adjustment—Hoses and connections—Gulp valve—Servo (if fitted)—Carburetter limit valve or mechanical condition</p> <p>Breaker points—Distributor and drive mechanical condition</p> <p>Distributor adjustment</p> <p>Carburetter adjustment—Hoses and connections—Gulp valve—Crankcase emission valve—Servo (if fitted)—Carburetter limit valve or mechanical condition—Air pump—Check valve—Spark plugs</p> <p>Hoses and connections—Gulp valve—Inlet manifold leaks—carburetter limit valve—Valves or seats—Piston rings</p>	 <p>Pattern 2</p>  <p>Pattern 3</p>
<p>Variation of 2° maximum</p> <p>See Pattern 2 (Trace inverted)</p> <p>3° max. variation. See Pattern 3 (inset A correct; inset B—overlap indicates cam error)</p> <p>Standard pattern</p> <p>See Pattern 4 (lack of oscillations indicate fault)</p> <p>See Pattern 1 (inset B)</p> <p>See Pattern 5; voltage 6—9 kV</p>	<p>Distributor and drive mechanical condition</p> <p>Ignition circuit connections—Ignition coil</p> <p>Distributor mechanical condition (cam)</p> <p>Spark plugs and leads—Breaker points—Carburetter adjustment—Hoses and connections—Gulp valve—Servo (if fitted)</p> <p>Ignition coil—Condenser</p> <p>Breaker points—Condenser</p> <p>Spark plugs and leads—Distributor cap and rotor—Carburetter adjustment (multi-carburetters)</p>	 <p>Pattern 4</p>
<p>See Pattern 6; acceptable voltage rise 6 to 10 kV</p> <p>Initial rich, lean off at throttle closure</p>	<p>Spark plugs and leads</p> <p>Carburetter limit valve and mechanical condition—Hoses and connections—Gulp valve—Air pump</p>	 <p>Pattern 5</p>
<p>See 'TUNING DATA'</p> <p>Standard pattern; minimum reserve <math>\frac{2}{3}</math> more than requirement</p> <p>Standard pattern</p> <p>14.5 volts; steady reading</p> <p>Leaning off following peak when test speed is reached</p> <p>No variation in reading at constant speed for 10 sec.</p>	<p>Distributor mechanical condition, vacuum unit, centrifugal weights and springs</p> <p>Ignition coil—H.T. circuit insulation</p> <p>H.T. leads—Distributor cap and rotor</p> <p>Cut-out—Voltage regulator—Dynamo/Alternator</p> <p>Hoses and connections—Carburetter adjustment—Air cleaners—Gulp valve—Air pump—Check valve—Injectors</p> <p>Exhaust system</p>	 <p>Pattern 6</p>